



Seltmann
Weiden

HOTEL

HIGH LIGHTS



MADE IN GERMANY

We produce in Germany



INDEX

4-5	BLUES white	40-41	MERAN Steak & More
6-9	BLUES »Percussion«	42-43	MERAN Organic
10-11	GOOD MOOD white »Mármaros« »Black Line«	44-45	PASO Fine Dining
12-13	MAXIM Basic	46-47	SALZBURG
14-15	MAXIM Coup Fine Dining	48-53	COUP FINE DINING »Fashion«
16-17	MAXIM Organic	54-55	COUP FINE DINING »Karma«
18-19	DIAMANT	56-59	COUP FINE DINING BUFFET GOURMET »Fantastic« + Bowls
20-21	COUP FINE DINING	60-63	COUP FINE DINING »Country Life«
22-23	SAVOY	64-65	COUP FINE DINING »Reflections« »Growth« »Oak«
24-25	SAVOY square / rectangular	66-67	COUP FINE DINING »Blue Sea«
26-27	SAVOY »Grand Blue«	68-71	BUFFET GOURMET
28-31	MANDARIN incl. Event	72-73	MUG TO GO
32-33	COFFE-E-MOTION	74-75	COMMUNITY
34-35	LAGUNA	76-77	VITALIS / IMPERIAL
36-39	MERAN Basic		





ARTIKEL	VE ¹	Art.-Nr. ²
Coffee pot 0,40 ltr.	2	001.756609
Tea pot 0,50 ltr.	2	001.756424
Warming plate 1069	1	001.756270
Sugar bowl 0,27 ltr.	1	001.756272
Creamer 0,29 ltr.	1	001.756271
Cup 0,18 ltr. stackable	6	001.756262
Saucer 16,5 cm	6	001.756263
Cup 0,25 ltr.	6	001.756747
Saucer 16,5 cm	6	001.756263
Cup 0,09 ltr. stackable	6	001.756357
Saucer 13,5 cm	6	001.756748
Mug with handle 0,28 ltr. stackable	6	001.756358
Cup 0,18 ltr.	6	001.756428
Saucer 16,5 cm	6	001.756263
Cup 0,22 ltr.	6	001.756429
Saucer 16,5 cm	6	001.756263
Cup 0,37 ltr.	6	001.756430
Saucer 16,5 cm	6	001.756263
Cup 0,09 ltr.	6	001.756427
Saucer 13,5 cm	6	001.756748
Mug with handle 0,28 ltr.	6	001.756359
Salt and pepper set	1	001.756284
Egg cup with rest	6	001.756283



ARTIKEL	VE ¹	Art.-Nr. ²
Plate flat 33 cm	6	001.756264
Plate flat 30 cm	6	001.756265
Plate flat 28 cm	6	001.756276
Plate flat 26 cm	6	001.756266
Plate flat 23 cm	6	001.756277
Plate flat 21,5 cm	6	001.756360
Plate flat 17 cm	6	001.756267
Plate deep 23 cm	6	001.756278
Plate deep 19 cm	6	001.756268
Pasta plate deep 30 cm	2	001.756269
Pasta plate deep 27 cm	2	001.756279
Soup cup 0,27 ltr.	6	001.756746
Saucer 16,5 cm	6	001.756263
Gravy boat 0,55 ltr.	1	001.756275
Bowl round 30 cm	1	001.756289
Bowl round 21 cm	2	001.756288
Bowl round 15,5 cm	4	001.756287
Bowl round 13 cm	6	001.756749
Platter oval 35 cm	2	001.756282
Platter oval 31 cm	2	001.756281
Platter oval 28 cm	2	001.756362
Platter oval 25 cm	2	001.756280
Bowl 13 cm	4	001.757082
Bowl 17,5 cm	2	001.757083
Bowl 20 cm	2	001.757084
Bowl 25 cm	2	001.757085
Bowl 28 cm	2	001.757086

¹ PU = Packing Unit

² Item-No refers to undecorated articles



	ARTIKEL	VE ¹	Art.-Nr.
	Coffee pot 0,40 ltr.	2	001.756612 ² 001.756653 ³
	Tea pot 0,50 ltr.	2	001.756571 ² 001.756615 ³
	Warming plate 1069	1	001.756572 ² 001.756616 ³
	Sugar bowl 0,27 ltr.	1	001.756573 ² 001.756617 ³
	Creamer 0,29 ltr.	1	001.756574 ² 001.756618 ³
	Cup 0,18 ltr. stackable	6	001.756575 ² 001.756619 ³
	Saucer 16,5 cm	6	001.756596 ² 001.756640 ³
	Cup 0,25 ltr.	6	001.756751 ² 001.756755 ³
	Saucer 16,5 cm	6	001.756596 ² 001.756640 ³
	Cup 0,09 ltr. stackable	6	001.756576 ² 001.756620 ³
	Saucer 13,5 cm	6	001.756752 ² 001.756756 ³
	Mug with handle 0,28 ltr. stackable	6	001.756577 ² 001.756621 ³
	Cup 0,18 ltr.	6	001.756578 ² 001.756622 ³
	Saucer 16,5 cm	6	001.756596 ² 001.756640 ³
	Cup 0,22 ltr.	6	001.756579 ² 001.756623 ³
	Saucer 16,5 cm	6	001.756596 ² 001.756640 ³
	Cup 0,37 ltr.	6	001.756580 ² 001.756625 ³
	Saucer 16,5 cm	6	001.756596 ² 001.756640 ³
	Cup 0,09 ltr.	6	001.756581 ² 001.756624 ³
	Saucer 13,5 cm	6	001.756752 ² 001.756756 ³
	Mug with handle 0,28 ltr.	6	001.756582 ² 001.756626 ³
	Salt and pepper set	1	001.756583 ² 001.756627 ³
	Egg cup with rest	6	001.756584 ² 001.756628 ³

¹ PU = Packing Unit

	ARTIKEL	VE ¹	Art.-Nr.
	Plate flat 33 cm	6	001.756585 ² 001.756629 ³
	Plate flat 30 cm	6	001.756586 ² 001.756630 ³
	Plate flat 28 cm	6	001.756587 ² 001.756631 ³
	Plate flat 26 cm	6	001.756588 ² 001.756632 ³
	Plate flat 23 cm	6	001.756589 ² 001.756633 ³
	Plate flat 21,5 cm	6	001.756590 ² 001.756634 ³
	Plate flat 17 cm	6	001.756591 ² 001.756635 ³
	Plate deep 23 cm	6	001.756592 ² 001.756636 ³
	Plate deep 19 cm	6	001.756594 ² 001.756637 ³
	Pasta plate deep 30 cm	2	001.756593 ² 001.756638 ³
	Pasta plate deep 27 cm	2	001.756595 ² 001.756639 ³
	Soup cup 0,27 ltr.	6	001.756750 ² 001.756754 ³
	Saucer 16,5 cm	6	001.756596 ² 001.756640 ³
	Gravy boat 0,55 ltr.	1	001.756597 ² 001.756641 ³
	Bowl round 30 cm	1	001.756600 ² 001.756644 ³
	Bowl round 21 cm	2	001.756599 ² 001.756643 ³
	Bowl round 15,5 cm	4	001.756598 ² 001.756642 ³
	Bowl round 13 cm	6	001.756753 ² 001.756757 ³
	Platter oval 35 cm	2	001.756604 ² 001.756648 ³
	Platter oval 31 cm	2	001.756603 ² 001.756647 ³
	Platter oval 28 cm	2	001.756602 ² 001.756646 ³
	Platter oval 25 cm	2	001.756601 ² 001.756645 ³
	Bowl 13 cm	4	001.757087 ² 001.757092 ³
	Bowl 17,5 cm	2	001.757088 ² 001.757093 ³
	Bowl 20 cm	2	001.757089 ² 001.757094 ³
	Bowl 25 cm	2	001.757090 ² 001.757095 ³
	Bowl 28 cm	2	001.757091 ² 001.757096 ³



- [2] »arctic blue« 57717 [3] »pearl grey« 57718
[4] »sand beige« 57719 [5] »sage green« 57720

B

BLUES


»PERCUSSION«

[4] »sand beige« 57719

[5] »sage green« 57720

	ARTIKEL	VE¹	Art.-Nr.
	Coffee pot 0,40 ltr.	2	001.756694 ^a 001.756735 ^b
	Tea pot 0,50 ltr.	2	001.756656 ^a 001.756697 ^b
	Warming plate 1069	1	001.756657 ^a 001.756698 ^b
	Sugar bowl 0,27 ltr.	1	001.756658 ^a 001.756699 ^b
	Creamer 0,29 ltr.	1	001.756659 ^a 001.756700 ^b
	Cup 0,18 ltr. stackable	6	001.756660 ^a 001.756701 ^b
	Saucer 16,5 cm	6	001.756681 ^a 001.756722 ^b
	Cup 0,25 ltr.	6	001.756759 ^a 001.756763 ^b
	Saucer 16,5 cm	6	001.756681 ^a 001.756722 ^b
	Cup 0,09 ltr. stackable	6	001.756661 ^a 001.756702 ^b
	Saucer 13,5 cm	6	001.756760 ^a 001.756764 ^b
	Mug with handle 0,28 ltr. stackable	6	001.756662 ^a 001.756703 ^b
	Cup 0,18 ltr.	6	001.756663 ^a 001.756704 ^b
	Saucer 16,5 cm	6	001.756681 ^a 001.756722 ^b
	Cup 0,22 ltr.	6	001.756664 ^a 001.756705 ^b
	Saucer 16,5 cm	6	001.756681 ^a 001.756722 ^b
	Cup 0,37 ltr.	6	001.756665 ^a 001.756706 ^b
	Saucer 16,5 cm	6	001.756681 ^a 001.756722 ^b
	Cup 0,09 ltr.	6	001.756666 ^a 001.756707 ^b
	Saucer 13,5 cm	6	001.756760 ^a 001.756764 ^b
	Mug with handle 0,28 ltr.	6	001.756667 ^a 001.756708 ^b
	Salt and pepper set	1	001.756668 ^a 001.756709 ^b
	Egg cup with rest	6	001.756669 ^a 001.756710 ^b

¹ PU = Packing Unit

	ARTIKEL	VE¹	Art.-Nr.
	Plate flat 33 cm	6	001.756670 ^a 001.756711 ^b
	Plate flat 30 cm	6	001.756671 ^a 001.756712 ^b
	Plate flat 28 cm	6	001.756672 ^a 001.756713 ^b
	Plate flat 26 cm	6	001.756673 ^a 001.756714 ^b
	Plate flat 23 cm	6	001.756674 ^a 001.756715 ^b
	Plate flat 21,5 cm	6	001.756675 ^a 001.756716 ^b
	Plate flat 17 cm	6	001.756676 ^a 001.756717 ^b
	Plate deep 23 cm	6	001.756677 ^a 001.756718 ^b
	Plate deep 19 cm	6	001.756678 ^a 001.756719 ^b
	Pasta plate deep 30 cm	2	001.756679 ^a 001.756720 ^b
	Pasta plate deep 27 cm	2	001.756680 ^a 001.756721 ^b
	Soup cup 0,27 ltr.	6	001.756758 ^a 001.756762 ^b
	Saucer 16,5 cm	6	001.756681 ^a 001.756722 ^b
	Gravy boat 0,55 ltr.	1	001.756682 ^a 001.756723 ^b
	Bowl round 30 cm	1	001.756685 ^a 001.756726 ^b
	Bowl round 21 cm	2	001.756684 ^a 001.756725 ^b
	Bowl round 15,5 cm	4	001.756683 ^a 001.756724 ^b
	Bowl round 13 cm	6	001.756761 ^a 001.756765 ^b
	Platter oval 35 cm	2	001.756689 ^a 001.756730 ^b
	Platter oval 31 cm	2	001.756688 ^a 001.756729 ^b
	Platter oval 28 cm	2	001.756687 ^a 001.756728 ^b
	Platter oval 25 cm	2	001.756686 ^a 001.756727 ^b
	Bowl 13 cm	4	001.757097 ^a 001.757102 ^b
	Bowl 17,5 cm	2	001.757098 ^a 001.757103 ^b
	Bowl 20 cm	2	001.757099 ^a 001.757104 ^b
	Bowl 25 cm	2	001.757100 ^a 001.757105 ^b
	Bowl 28 cm	2	001.757101 ^a 001.757106 ^b



G

GOOD MOOD

WHITE | »MÁRMAROS« | »BLACK LINE«

ITEM DESCRIPTION	PU ¹	Item-No
Coffee pot 1 0,38 ltr. / 13.3 oz.	2	001.751096 ² 001.751228 ³ 001.755599 ⁴
Sugar Bowl 0,18 ltr. / 6.3 oz.	1	001.751108 ² 001.751232 ³ 001.755600 ⁴
Creamer 0,14 ltr. / 4.7 oz.	1	001.751102 ² 001.751235 ³ 001.755601 ⁴
Cup 0,09 ltr. / 3.3 oz.	6	001.751103 ² 001.751236 ³ 001.755602 ⁴
Saucer M5402-13 13 cm / 5.2 inch	6	001.751099 ² 001.751231 ³ 001.755603 ⁴
Cup 0,18 ltr. / 6.3 oz.	6	001.751104 ² 001.751237 ³ 001.755604 ⁴
Cup 0,25 ltr. / cup 8.7 oz.	6	001.751107 ² 001.751240 ³ 001.755605 ⁴
Mug with handle 0,28 ltr. / 9.7 oz.	6	001.751106 ² 001.751239 ³ 001.755606 ⁴
Combi saucer M5402-16 16 cm / 6.3 inch	6	001.751105 ² 001.751238 ³ 001.755607 ⁴
Plate flat M5397-30 30 cm / 11.9 inch	2	001.751089 ² 001.751219 ³ 001.755608 ⁴
Plate flat M5397-28 28 cm / 11.1 inch	2	001.751088 ² 001.751218 ³ 001.755609 ⁴
Plate flat M5397-26 26 cm / 10.2 inch	6	001.751087 ² 001.751217 ³ 001.755610 ⁴
Plate flat M5397-21 21 cm / 8.2 inch	6	001.751430 ² 001.751443 ³ 001.755611 ⁴
Plate flat M5397-16 16 cm / 6.3 inch	6	001.751086 ² 001.751216 ³ 001.755612 ⁴
Plate flat oval M5398-29 29 x 21 cm / 11.6 x 8.3 inch	2	001.751093 ² 001.751225 ³ 001.755613 ⁴
Plate flat oval M5398-32 32 x 23 cm / 12.7 x 9.0 inch	2	001.751094 ² 001.751226 ³ 001.755614 ⁴
Plate flat oval M5398-36 36 x 26 cm / 14.4 x 10.2 inch	2	001.751095 ² 001.751227 ³ 001.755615 ⁴

¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No
Bowl semi-high M5399-12 12 cm / 4.8 inch	2	001.751424 ² 001.751437 ³ 001.755616 ⁴
Bowl semi-high M5399-16 16 cm / 6.3 inch	2	001.751090 ² 001.751220 ³ 001.755617 ⁴
Bowl semi-high M5399-21 21 cm / 8.2 inch	1	001.751091 ² 001.751221 ³ 001.755618 ⁴
Bowl semi-high M5399-26 26 cm / 10.3 inch	1	001.751092 ² 001.751222 ³ 001.755619 ⁴
Bowl high M5400-16 16 cm / 6.4 inch	1	001.751425 ² 001.751438 ³ 001.755620 ⁴
Bowl high M5400-21 21 cm / 8.4 inch	1	001.751426 ² 001.751439 ³ 001.755621 ⁴
Plate deep coup M5404-16 16 cm / 6.3 inch	4	001.751428 ² 001.751441 ³ 001.755622 ⁴
Plate deep coup M5404-21 21 cm / 8.3 inch	2	001.751427 ² 001.751440 ³ 001.755623 ⁴
Plate deep coup M5404-26 26 cm / 10.3 inch	2	001.751429 ² 001.751442 ³ 001.755624 ⁴
Bowl high 8 cm / 3.1 inch	6	001.751100 ² 001.751223 ³ 001.755625 ⁴
Bowl low M5403 8 cm / 3.1 inch	6	001.751101 ² 001.751224 ³ 001.755626 ⁴

² weiß uni

³ »Mármaros« 57570

⁴ »Black Line« 10826



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.724967
Tea pot 1 0,55 ltr. / 18.3 oz.	2	001.724970
Warming plate small	1	001.724994
Tea strainer (ACCESSOIRE)	2	001.750850
Rest for tea strainer / Sugar bag container	6	001.726871
Sugar bowl 2 0,28 ltr. / 9.3 oz.	1	001.724974
Sugar dish 8 cm / 3.2 inch	12	001.724973
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.724977
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.724978
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.724979
Cup 0,09 ltr. / 3.0 oz.	6	001.724984
Saucer 13,5 cm / 5.4 inch	6	001.724983
Cup 1 0,18 ltr. / 6.0 oz.	6	001.724985
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup 2 0,16 ltr. / 5.3 oz.	6	001.724986
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup 0,25 ltr. / 8.3 oz.	6	001.724987
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup 0,32 ltr. / 10.7 oz.	6	001.724988
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.724992
Cup non stackable 0,09 ltr. / 3.0 oz.	6	001.724982
Saucer 13,5 cm / 5.4 inch	6	001.724983
Cup non stackable 0,18 ltr. / 6.0 oz.	6	001.724989
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup non stackable 0,22 ltr. / 7.3 oz.	6	001.724990
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup non stackable 0,37 ltr. / 12.3 oz.	6	001.724980
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Mug with handle non stackable 0,28 ltr. / 9.3 oz.	6	001.724993
Cup 0,21 ltr. / 7.0 oz.	6	001.724981
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Cup 0,42 ltr. / 14.0 oz.	6	001.732567
Saucer 1 16,5 cm / 6.7 inch	6	001.724991

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat 33 cm / 13.1 inch	6	001.724938
Plate flat 30 cm / 11.9 inch	6	001.724937
Plate flat 28 cm / 11.2 inch	6	001.724936
Plate flat 26 cm / 10.3 inch	6	001.724935
Plate flat 23 cm / 9.1 inch	6	001.724934
Plate flat 21,5 cm / 8.5 inch	6	001.724933
Plate flat 17 cm / 6.7 inch	6	001.724932
Plate deep 23 cm / 9.1 inch	6	001.724939
Salad plate 19 cm / 7.5 inch	6	001.724949
Pasta plate deep 30 cm / 12.0 inch	2	001.724950
Pasta plate deep 27 cm / 10.8 inch	2	001.724951
Soup cup 0,27 ltr. / 10.0 oz.	6	001.724940
Saucer 1 16,5 cm / 6.7 inch	6	001.724991
Eventbowl oval 5257 18 cm / 7.1 x 4.9 inch	2	001.724941
Gravy boat 0,45 ltr. / 15.0 oz.	2	001.724952
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.724953
Bowl small 8,5 cm / 3.4 inch	6	001.724946
Bowl large 11 cm / 4.4 inch	6	001.724945
Party-spoon	6	001.724997
Bowl round 13 cm / 5.2 inch	4	001.724942
Bowl round 15 cm / 5.9 inch	2	001.724943
Bowl round 18 cm / 7.1 inch	2	001.724944
Bowl round 21 cm / 8.3 inch	2	001.724947
Bowl round 24 cm / 9.4 inch	2	001.724948
Oval plate flat 25 cm / 10.0 x 7.0 inch	2	001.724962
Oval plate flat 28 cm / 11.2 x 8.3 inch	2	001.724963
Oval plate flat 31 cm / 12.3 x 9.4 inch	2	001.724964
Oval plate flat 35 cm / 13.9 x 10.9 inch	2	001.724965
Egg cup with rest	6	001.724954
Set salt and pepper	1	001.724961

¹ PU = Packing Unit

² Item-No refers to undecorated articles



M AXIM

COUP FINE DINING



ITEM DESCRIPTION	PU ¹	Item-No ²
 Cup M5389 0,08 ltr. / 2.7 oz.	6	001.744594
 Cup M5389 0,19 ltr. / 6.3 oz.	6	001.744595
 Cup M5389 0,22 ltr. / 7.3 oz.	6	001.744596
 Cup 0,28 ltr. / 9.3 oz.	6	001.745041
 Cup M5389 0,35 ltr. / 11.7 oz.	6	001.744597
 Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.744598
 Saucer square M5387 13 x 13 cm / 5.2 x 5.2 inch	6	001.744599
 Saucer square M5387 16 x 16 cm / 6.3 x 6.3 inch	6	001.744600
 Saucer round M5390 13,5 cm / 5.2 inch	6	001.744601
 Saucer round M5390 16,5 cm / 6.4 inch	6	001.744602
 Showplate flat M5380-33-D 33 cm / 13.1 inch	4	001.729621
 Plate flat coup M5380-30-D 30 cm / 12.0 inch	4	001.729615
 Plate flat coup M5380-28-D 28 cm / 11.0 inch	6	001.729614
 Plate flat coup M5380-26-D 26 cm / 10.3 inch	6	001.729613
 Plate flat coup M5380-21,5-D 21,5 cm / 8.5 inch	6	001.729612
 Plate flat coup M5380-16,5-D 16,5 cm / 6.5 inch	6	001.729611
 Bowl coup M5381-28-D 28 cm / 11.0 inch	4	001.729620
 Bowl coup M5381-26-D 26 cm / 10.3 inch	6	001.729619
 Bowl coup M5381-23-D 23 cm / 9.2 inch	6	001.729618
 Bowl coup M5381-20-D 20 cm / 7.9 inch	6	001.729617
 Bowl coup M5381-14,5-D 14,5 cm / 5.7 inch	6	001.729616

¹ PU = Packing Unit

² Item-No refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
 Platter coup M5379-33x18-D 33 x 18 cm / 13.0 x 7.0 inch	2	001.733825
 Platter coup M5379-40x25,5-D 40 x 25,5 cm / 16.0 x 10.2 inch	2	001.729622
 Platter coup M5379-43x19-D 43 x 19 cm / 17.1 x 7.5 inch	2	001.729623
 Platter coup M5379-35x11-D 35 x 11 cm / 13.9 x 4.5 inch	2	001.733824
 Platter coup M5379-44x14-D 44 x 14 cm / 17.4 x 6.0 inch	2	001.729624
 Duo plate 44 cm / 17.5 x 5.6 inch	2	001.732566
 Bowl high 0,18 ltr. / 6.0 oz.	6	001.732565
 Bowl low 0,21 ltr. / 7.0 oz.	6	001.732564
 Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.743541
 Plate flat coup square M5383 26 x 26 cm / 10.2 x 10.2 inch	6	001.743540
 Plate flat coup square M5383 22 x 22 cm / 8.7 x 8.7 inch	6	001.743539
 Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.743538
 Bowl coup square M5384 26 x 26 cm / 10.2 x 10.2 inch	4	001.743546
 Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.743545
 Bowl coup square M5384 17,5 x 17,5 cm / 6.9 x 6.9 inch	6	001.743544
 Bowl coup square M5384 13 x 13 cm / 5.0 x 5.0 inch	6	001.743543
 Plate flat coup rectangular M5385 35 x 20 cm / 13.9 x 8.0 inch	2	001.743542
 Plate flat coup rectangular M5386 25,5 x 18 cm / 10.2 x 7.0 inch	2	001.743547
 Plate flat coup rectangular M5388 38 x 14 cm / 15.2 x 5.6 inch	2	001.743548





M AXIM

ORGANIC



ITEM DESCRIPTION

PU¹ Item-No²

Gourmet-plate flat organic M5340 34 cm / 13.5 x 11.3 inch	2	001.725345
Gourmet-plate flat organic M5318 29,5 cm / 11.6 x 9.3 inch	6	001.725344
Gourmet-plate flat organic M5319 24 cm / 9.5 x 7.8 inch	6	001.725343
Gourmet-plate flat organic M5339 19 cm / 7.5 x 6.5 inch	6	001.725342



ITEM DESCRIPTION

PU¹ Item-No²

Gourmet-bowl deep organic M5317 26 cm / 9.8 x 8.6 inch	2	001.725350
Gourmet-bowl deep organic M5316 20 cm / 7.8 x 6.5 inch	2	001.725349
Gourmet-bowl deep organic M5374 16 cm / 6.2 x 5.4 inch	4	001.725348
Gourmet-bowl deep organic M5373 12 cm / 4.7 x 3.9 inch	6	001.725347
Gourmet-bowl deep organic M5372 8 cm / 3.3 x 2.6 inch	6	001.725346



¹ PU = Packing Unit

² Item-No refers to undecorated articles



DIAMANT



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.700797
Tea pot 1 0,45 ltr. / 15.0 oz.	2	001.700798
Warming plate 1069 small	1	001.700822
Tea strainer (ACCESSOIRE)	2	001.750850
Rest for tea strainer	6	001.700819
Sugar bowl 2 0,21 ltr. / 7.0 oz.	1	001.700799
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.700800
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.700801
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.700802
Creamer 4 0,50 ltr. / 18.7 oz.	1	001.720210
Cup 0,08 ltr. / 2.7 oz.	12	001.700810
Saucer 13,5 cm / 5.3 inch	12	001.700809
Cup 1 0,18 ltr. / 6.0 oz.	6	001.700812
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Cup 2 0,16 ltr. / 5.3 oz.	6	001.700814
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Cup 0,25 ltr. / 8.3 oz.	6	001.700816
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.700820
Cup non stackable 0,08 ltr. / 2.7 oz.	12	001.700806
Saucer 13,5 cm / 5.3 inch	12	001.700809
Cup non stackable 0,23 ltr. / 7.7 oz.	6	001.700808
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Cup non stackable 0,37 ltr. / 12.3 oz.	6	001.705625
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Mug with handle non stackable 0,30 ltr. / 10.0 oz.	6	001.700821
Cup 0,21 ltr. / 7.0 oz.	6	001.700804
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Vase	2	001.700823
Candleholder	2	001.700824
Napkin ring	6	001.703774
Plate flat 33 cm / 13.0 inch	6	001.700773
Plate flat 31,5 cm / 12.4 inch	6	001.701737
Plate flat 29 cm / 11.4 inch	6	001.700775
Plate flat 26 cm / 10.3 inch	6	001.700772
Plate flat 22,5 cm / 9.0 inch	6	001.700774
Plate flat 19 cm / 7.7 inch	6	001.700771
Plate flat 17 cm / 6.8 inch	6	001.700770



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate deep 23 cm / 9.3 inch	6	001.700776
Salad plate 20 cm / 8.0 inch	6	001.700784
Pasta plate deep 30 cm / 11.7 inch	2	001.700785
Pasta plate deep 27 cm / 10.7 inch	2	001.700786
Soup cup 0,27 ltr. / 9.0 oz.	6	001.700778
Saucer 1 17,1 cm / 6.7 inch	6	001.700811
Eventbowl oval 5257 18 cm / 7.0 x 5.0 inch	2	001.700779
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.700787
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.700790
Butter pad small* 0,06 ltr. / 2.0 oz.	2	001.703727
Butter pad large** 0,13 ltr. / 4.3 oz.	2	001.703726
Bowl round 15 cm / 5.7 inch	4	001.700780
Bowl round 18 cm / 7.4 inch	2	001.705623
Bowl round 23 cm / 9.2 inch	2	001.700781
Bowl round 26 cm / 10.0 inch	2	001.700782
Oval plate flat 33 cm / 13.0 x 10.4 inch	2	001.700795
Oval plate flat 38 cm / 15.2 x 12.2 inch	2	001.700796
Egg cup with rest	6	001.700791
Set salt and pepper	1	001.700794
Salt shaker	2	001.700792
Pepper shaker	2	001.700793
Eventplate deep round 26 cm / 10.6 inch	2	001.712395
Eventplate flat round 25 cm / 10.0 inch	6	001.712394
Eventbowl sloping 18 cm / 7.2 inch	4	001.712398
Eventbowl sloping 22 cm / 8.6 inch	2	001.712399

*suitable for saucer 13,5 cm / 5.3 inch

**suitable for saucer 1 17,1 cm / 6.7 inch

¹ PU = Packing Unit

² Item-No refers to undecorated articles



CUP FINE DINING

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742664
Tea pot 0,65 ltr. / 21.6 oz.	2	001.742675
Sugar bowl (LIFE) 0,26 ltr. / 8.6 oz.	1	001.737201
Creamer 0,26 ltr. / 8.6 oz.	1	001.737204
Cup M5389 0,08 ltr. / 2.6 oz.	6	001.742665
Cup (LIFE) 0,14 ltr. / 4.6 oz.	6	001.737209
Cup 0,19 ltr. / 6.3 oz.	6	001.742666
Cup M5389 0,22 ltr. / 7.3 oz.	6	001.742667
Cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.737208
Cup M5389 0,35 ltr. / 11.6 oz.	6	001.742668
Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742669
Mug with handle M5389 0,38 ltr. / 12.6 oz.	1	001.742670
Saucer square M5387* 13 x 13 cm / 5.0 x 5.0 inch	6	001.742671
Saucer square M5387** 16 x 16 cm / 6.3 x 6.3 inch	6	001.742672
Saucer round M5390* 13,5 cm / 5.3 inch	6	001.742673
Saucer round M5390** 16,5 cm / 6.5 inch	6	001.742674
Showplate flat M5380 33 cm / 13.0 inch	4	001.729476
Plate flat coup M5380 30 cm / 12.0 inch	6	001.729470
Plate flat coup M5380 28 cm / 11.0 inch	6	001.729469
Plate flat coup M5380 26 cm / 10.3 inch	6	001.729468
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.729467
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.729466
Bowl coup M5381 28 cm / 11.0 inch	4	001.729475
Bowl coup M5381 26 cm / 10.3 inch	6	001.729474
Bowl coup M5381 23 cm / 9.3 inch	6	001.729473
Bowl coup M5381 20 cm / 7.8 inch	6	001.729472
Bowl coup M5381 14,5 cm / 5.8 inch	6	001.729471
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733789
Platter coup M5379 40 x 25,5 cm / 16.0 x 10.3 inch	2	001.729477
Platter coup M5379 43 x 19 cm / 17.3 x 7.5 inch	2	001.729478
Platter coup M5379 35 x 11 cm / 13.8 x 4.5 inch	2	001.733788
Platter coup M5379 44 x 14 cm / 17.3 x 5.6 inch	2	001.729479
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732630
Bowl high 0,18 ltr. / 6.3 oz.	6	001.732631
Bowl low 0,21 ltr. / 6.6 oz.	6	001.732632

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.742656
Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.742655
Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.742654
Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.742653
Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.742661
Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.742660
Bowl coup square M5384 17,5 x 17,5 cm / 6.8 x 6.8 inch	6	001.742659
Bowl coup square M5384 13 x 13 cm / 5.0 x 5.0 inch	6	001.742658
Plate flat coup rectangular M5385 35 x 20 cm / 14.0 x 8.0 inch	2	001.742657
Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.742662
Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.742663
Covered vegetable (LIFE) 3,00 ltr. / 100.0 oz.	1	001.737227
Gravy boat (LIFE) 0,60 ltr. / 20.0 oz.	1	001.737230
Egg cup with rest (LIFE)	6	001.737231
Bowl with handle 0,60 ltr. (LIFE)	2	001.737235
Bowl with handle 0,45 ltr. (LIFE)	2	001.757076
Bowl 13 cm	4	001.757107
Bowl 17,5 cm	2	001.757108
Bowl 20 cm	2	001.757109
Bowl 25 cm	2	001.757110
Bowl 28 cm	2	001.757111

* suitable for cup M5389 0,08 ltr. / 2.6 oz.,
cup (LIFE) 0,14 ltr. / 4.6 oz.

**suitable for all cups, except cup M5389 0,08 ltr. / 2.6 oz.,
cup (LIFE) 0,14 ltr. / 4.6 oz.

¹ PU = Packing Unit

² Item-No refers to undecorated articles





ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.505082
Tea pot 1 0,40 ltr. / 13.3 oz.	2	001.505355
Tea pot 2 0,75 ltr. / 25.0 oz.	2	001.505628
Warming plate small	1	001.509840
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.506564
Sugar dish 8 cm / 3.2 inch	12	001.506447
Creamer 00 0,03 ltr. / 1.0 oz.	12	001.506837
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.506954
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.507071
Cup 1 0,18 ltr. / 6.0 oz.	6	001.508787
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Cup 0,09 ltr. / 3.0 oz.	12	001.508514
Saucer 14,5 cm / 5.7 inch	12	001.508358
Cup 0,36 ltr. / 12.0 oz.	6	001.509606
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Cup 0,22 ltr. / 7.3 oz.	6	001.509333
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Cup non stackable 0,18 ltr. / 6.0 oz.	6	001.507968
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Cup non stackable 0,09 ltr. / 3.0 oz.	12	001.508241
Saucer 14,5 cm / 5.7 inch	12	001.508358
Cup non stackable 0,22 ltr. / 7.7 oz.	6	001.507422
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Cup non stackable 0,37 ltr. / 12.3 oz.	6	001.507895
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.509723
Egg cup with rest	6	001.502742
Set salt and pepper	1	001.503600
Vase	2	001.509879
Candleholder	2	001.510230
Ash tray	4	001.510113
Party-spoon	6	001.510347
Bowl sloping 8,5 cm / 3.4 inch	6	001.498374
Bowl sloping 11 cm / 4.4 inch	6	001.498881
Bowl square 9 cm / 3.5 x 3.5 inch	6	001.498491
Bowl square 11 cm / 4.8 x 4.8 inch	6	001.498764

¹ PU = Packing Unit

² Item-No refers to undecorated articles



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 34 cm / 13.4 inch	2	001.501143
Plate flat with rim 33 cm / 13.0 inch	6	001.497321
Plate flat with rim 30 cm / 12.0 inch	6	001.497165
Plate flat with rim 28 cm / 11.3 inch	6	001.497009
Plate flat with rim 26 cm / 10.4 inch	6	001.496853
Plate flat with rim 23 cm / 9.3 inch	6	001.496697
Plate flat with rim 21 cm / 8.5 inch	6	001.496541
Plate flat with rim 18 cm / 6.8 inch	6	001.496385
Plate flat with rim 16 cm / 6.5 inch	6	001.496307
Gourmetplate round 30 cm / 12.0 inch	2	001.500363
Gourmetplate round 27 cm / 10.6 inch	2	001.500519
Gourmetplate round 21 cm / 8.5 inch	6	001.501065
Gourmetplate round 18 cm / 7.3 inch	6	001.500987
Gourmetplate round 16 cm / 6.5 inch	6	001.500675
Gourmetplate round 12 cm / 4.8 inch	6	001.500831
Plate deep with rim 23 cm / 9.2 inch	6	001.497477
Salad plate deep 19 cm / 7.6 inch	6	001.500168
Soup cup 0,27 ltr. / 9.0 oz.	6	001.497789
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Eventbowl 5253 18 cm / 7.0 x 4.8 inch	4	001.697323
Tureen 2,90 ltr. / 96.7 oz.	1	001.501260
Gravy boat 0,35 ltr. / 11.7 oz.	2	001.501767
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.502625
Butter pad 0,04 ltr. / 1.3 oz.	2	001.502508
Bowl round 12 cm / 4.7 inch	6	001.497906
Bowl round 14 cm / 5.5 inch	4	001.498062
Bowl round 17 cm / 6.6 inch	2	001.498218
Bowl round 20 cm / 7.8 inch	2	001.498608
Bowl round 22 cm / 8.5 inch	2	001.498998
Bowl round 24 cm / 9.3 inch	2	001.499154
Bowl round 13 cm / 5.2 inch	4	001.499934
Bowl round 15 cm / 6.0 inch	4	001.500051
Oval platter 28 cm / 11.0 x 7.6 inch	2	001.504458
Oval platter 32 cm / 12.8 x 8.7 inch	2	001.504614
Oval platter 36 cm / 14.6 x 10.0 inch	2	001.504770
Plate rectangular 36 x 14 cm / 14.2 x 5.5 inch	2	001.504146
Plate rectangular 30 x 14 cm / 11.8 x 5.5 inch	2	001.503990
Plate rectangular 23 x 14 cm / 9.1 x 5.5 inch	2	001.503834
Plate rectangular 16 x 12 cm / 6.3 x 4.7 inch	2	001.503678
Duo plate 26 cm / 10.6 x 6.0 inch	2	001.504926
Bowl square 14 cm / 5.7 x 5.7 inch	6	001.499310
Bowl square 17,5 cm / 7.0 x 7.0 inch	2	001.499466
Bowl square 22 cm / 8.7 x 8.7 inch	2	001.499622



ITEM DESCRIPTION

PU¹ Item-No²

Plate flat with rim square 32 cm / 12.8 x 12.8 inch	6	001.626331
Plate flat with rim square 28 cm / 11.3 x 11.3 inch	6	001.626327
Plate flat with rim square 22,5 cm / 9.0 x 9.0 inch	6	001.620703
Plate flat with rim square 17 cm / 6.5 x 6.5 inch	6	001.645154
Plate flat with rim square 24,5 cm / 9.7 x 9.7 inch	6	001.620765
Plate rectangular 40 x 27,5 cm / 15.7 x 10.7 inch	2	001.684445
Plate rectangular 35 x 24,5 cm / 13.9 x 9.6 inch	2	001.654875
Plate rectangular 29,5 x 20 cm / 11.7 x 7.8 inch	6	001.684443
Plate deep rectangular 27,5 x 20,5 cm / 11.0 x 8.0 inch	2	001.684519
Gourmet-plate deep square 27 cm / 10.7 x 10.7 inch	6	001.626336
Gourmet-plate deep square 20,5 cm / 8.1 x 8.1 inch	6	001.621075
Gourmet-plate deep square 15,5 cm / 6.1 x 6.1 inch	6	001.620951
Gourmet-plate deep square 12 cm / 4.7 x 4.7 inch	6	001.621013
Saucer square 1* 16,4 cm / 6.5 x 6.5 inch	6	001.621323
Saucer square 14 cm / 5.5 x 5.5 inch	12	001.621385

ADDITIONAL ITEMS

ITEM DESCRIPTION

PU¹ Item-No²


Dipbowl oval (Jade Lotos) 9 cm / 4.5 x 3.5 inch	6	001.620889
Dipbowl oval (Jade Lotos) 14 cm / 7.9 x 5.2 inch	6	001.620827



* Combi-saucer

¹ PU = Packing Unit

² Item-No refers to undecorated articles





ITEM DESCRIPTION	PU ¹	Item-No
Plate flat with rim 34 cm / 13.4 inch	2	001.749573
Plate flat with rim 30 cm / 12.0 inch	6	001.749574
Plate flat with rim 28 cm / 11.3 inch	6	001.749575
Plate flat with rim 26 cm / 10.4 inch	6	001.749576
Plate flat with rim 21 cm / 8.5 inch	6	001.749577
Plate flat with rim 16 cm / 6.5 inch	6	001.749578
Gourmetplate round 27 cm / 10.6 inch	2	001.749579
Gourmetplate round 21 cm / 8.5 inch	6	001.749580



ITEM DESCRIPTION	PU ¹	Item-No
Plate deep with rim 23 cm / 9.2 inch	6	001.749581
Salad plate deep 19 cm / 7.6 inch	6	001.749582
Plate rectangular 35 x 24,5 cm / 13.9 x 9.6 inch	2	001.749583
Plate rectangular 29,5 x 20 cm / 11.7 x 7.8 inch	6	001.749584
Saucer 1 16,4 cm / 6.5 inch	6	001.749571
Saucer 14,5 cm / 5.7 inch	12	001.749572



¹ PU = Packing Unit



M ANDARIN



ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.7 oz.	2	001.681319
Tea pot 1 0,45 ltr. / 15.0 oz.	2	001.681320
Warming plate 1069 small	1	001.681347
Tea strainer (ACCESSOIRE)	2	001.750850
Rest for tea strainer	6	001.686022
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.681223
Sugar dish 8 cm / 3.1 inch	12	001.684448
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.681326
Creamer 2 0,25 ltr. / 8.3 oz.	1	001.681224
Cup 0,09 ltr. / 3.0 oz.	12	001.681339
Saucer oval 15,5 x 14 cm / 6.1 x 5.5 inch	6	001.681762
Saucer round 13,7 cm / 5.4 inch	12	001.681227
Cup 1 0,18 ltr. / 6.0 oz.	6	001.681342
Cup 0,25 ltr. / 8.3 oz.	6	001.681231
Mug with handle stackable 0,28 ltr. / 9.3 oz.	6	001.681232
Combi saucer oval 1 17,8 x 16,2 cm / 7.0 x 6.4 inch	6	001.681230
Combi saucer round 1 16 cm / 6.3 inch	6	001.681229
Cup 0,09 ltr. / 3.0 oz.	12	001.681225
Cup 0,18 ltr. / 6.0 oz.	6	001.681336
Cup 0,25 ltr. / 8.3 oz.	6	001.681226
Cup 0,37 ltr. / 12.3 oz.	6	001.681337
Mug with handle 0,28 ltr. / 9.3 oz.	6	001.681346
Egg cup with rest	6	001.686025
Set salt and pepper	1	001.681313
Plate flat oval 18 cm / 7.0 x 6.4 inch	6	001.681214
Plate flat oval 24 cm / 9.4 x 8.5 inch	6	001.681215
Plate flat oval 30 cm / 11.7 x 10.6 inch	6	001.681216
Plate flat oval 34 cm / 13.5 x 12.1 inch	6	001.681217
Plate flat oval 37,5 cm / 14.9 x 13.4 inch	2	001.681752



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate deep oval 25 cm / 9.8 x 9.2 inch	6	001.681218
Plate flat round 16 cm / 6.2 inch	6	001.681210
Plate flat round 23 cm / 9.0 inch	6	001.681211
Plate flat round 26 cm / 10.3 inch	6	001.681751
Plate flat round 28 cm / 11.0 inch	6	001.681212
Gourmet plate round 23 cm / 9.0 inch	6	001.681220
Gourmet plate round 27 cm / 10.6 inch	2	001.681761
Pasta plate deep round 26,5 cm / 10.4 inch	6	001.722893
Soup cup 0,27 ltr. / 9.0 oz.	6	001.681177
Saucer 1 oval 17,8 x 16,2 cm / 7.0 x 6.4 inch	6	001.681230
Saucer 1 round 16 cm / 6.3 inch	6	001.681229
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.681306
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.681309
Bowl oval 15 cm / 6.0 x 5.6 inch	6	001.683169
Bowl oval 17 cm / 6.6 x 6.1 inch	4	001.683170
Bowl oval 20 cm / 7.8 x 7.3 inch	2	001.681759
Bowl oval 24 cm / 9.4 x 8.7 inch	2	001.681760
Oval plate flat 28 cm / 11.0 x 8.2 inch	2	001.683768
Oval plate flat 31 cm / 12.2 x 9.1 inch	2	001.681221
Oval plate flat 35 cm / 13.7 x 8.7 inch	2	001.681222
Bowl 21 cm / 8.3 inch	2	001.683167



¹ PU = Packing Unit

² Item-No refers to undecorated articles



M ANDARIN

EVENT



ITEM DESCRIPTION	PU ¹	Item-No ²
Eventplate flat oval 25 cm / 9.9 x 9.0 inch	6	001.681754
Eventplate deep oval 22 cm / 8.8 x 7.8 inch	4	001.681757
Eventplate deep oval 25 cm / 10.4 x 9.4 inch	2	001.681758
Eventplate deep round 26 cm / 10.2 inch	2	001.681755
Eventbowl 8,5 cm / 3.3 inch	6	001.685643
Eventbowl 10,5 cm / 4.1 inch	6	001.685644
Eventbowl 16 cm / 6.3 inch	4	001.685645
Eventbowl 21 cm / 7.9 inch	2	001.685646
Eventspoon 12 cm	6	001.685654
Eventspoon 18 cm	4	001.685655
Eventbowl sloping 14 cm / 5.6 inch	6	001.685648
Eventbowl sloping 18 cm / 7.2 inch	4	001.685650
Eventbowl sloping 22 cm / 8.7 inch	2	001.685651



¹ PU = Packing Unit

² Item-No refers to undecorated articles



C OFFE-E-MOTION



ITEM DESCRIPTION	PU ¹	Item-No ²
Creamer M5341 0,25 ltr. / 8.3 oz.	1	001.718472
Sugar bowl with cover M5342 0,26 ltr. / 8.7 oz.	1	001.718469
Cup M5352 0,09 ltr. / 3.0 oz.	6	001.718477
Cup M5344 0,18 ltr. / 6.0 oz.	6	001.718476
Cup M5345 0,25 ltr. / 8.7 oz.	6	001.718482
Cup M5347 0,37 ltr. / 12.7 oz.	6	001.718480
Mug with handle M5348 0,30 ltr. / 10.0 oz.	6	001.718483
Mug with handle M5349 0,45 ltr. / 15.0 oz.	1	001.718484
Cup low M5364 0,18 ltr. / 6.0 oz.	6	001.720153
Cup low M5346 0,25 ltr. / 8.0 oz.	6	001.718481
Cup low M5365 0,37 ltr. / 12.3 oz.	6	001.720154
Saucer small M5354* 17,5 cm / 6.8 x 5.7 inch	6	001.718474
Saucer large M5350** 22 cm / 8.7 x 7.3 inch	6	001.718473



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat M5363 22 cm / 8.7 x 7.7 inch	6	001.720152
Plate flat M5351 25,5 cm / 10.0 x 9.0 inch	6	001.718462
Plate flat M5355 29 cm / 11.5 x 10.5 inch	6	001.718463
Plate flat M5356 33,5 cm / 13.2 x 11.7 inch	6	001.718464
Bowl round M5357 15 cm / 6.0 x 5.0 inch	2	001.718465
Bowl round M5358 20 cm / 8.0 x 6.9 inch	1	001.718466
Bowl round M5359 25 cm / 9.8 x 8.5 inch	1	001.718467
Bowl round M5360**** 0,50 ltr. / 18.3 oz.	1	001.718485
Saucer round M5361 small*** 12,5 cm / 5.0 inch	6	001.718478
Saucer round M5362 big** 17,5 cm / 6.9 inch	6	001.718479



¹ PU = Packing Unit

² Item-No refers to undecorated articles

* suitable for all cups

** suitable for cup M5433 0,18 ltr. / 6.0 oz., cup M5345 0,25 ltr. / 8.7 oz. cup M5347 0,37 ltr. / 12.7 oz., mug with handle M5348 0,30 ltr. / 10.0 oz. mug with handle M5349 0,35 ltr. / 15.0 oz., cup low M5364 0,18 ltr. / 6.0 oz. cup low M5346 0,25 ltr. / 8.0 oz., cup low M5365 0,37 ltr. / 12.3 oz.

*** suitable for cup M5352 0,09 ltr. / 3.0 oz.

**** suitable for saucer round M5362 large 17,5 cm / 6.9 inch



L AGUNA

ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.698919
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.698922
Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.698925
Creamer 2 0,25 ltr. / 8.0 oz.	1	001.698928
Cup 1 0,18 ltr. / 6.0 oz.	6	001.698946
Saucer 1 16 cm / 6.3 inch	6	001.698945
Cup 0,09 ltr. / 3.0 oz.	12	001.698943
Saucer 13,4 cm / 5.3 inch	12	001.698942
Cup 0,22 ltr. / 7.3 oz.	6	001.698949
Saucer 1 16 cm / 6.3 inch	6	001.698945
Cup non stackable 0,18 ltr. / 6.0 oz.	6	001.698937
Saucer 1 16 cm / 6.3 inch	6	001.698945
Cup non stackable 0,22 ltr. / 7.3 oz.	6	001.698931
Saucer 1 16 cm / 6.3 inch	6	001.698945
Egg cup with rest	6	001.702210
Set salt and pepper	1	001.702212
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.698950

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 30 cm / 12.0 inch	6	001.698898
Plate flat with rim 28 cm / 11.0 inch	6	001.698897
Plate flat with rim 26 cm / 10.3 inch	6	001.698896
Plate flat with rim 23 cm / 9.0 inch	6	001.698895
Plate flat with rim 21 cm / 8.5 inch	6	001.698894
Plate flat with rim 17 cm / 6.6 inch	6	001.698893
Pasta bowl deep 30 cm / 12.0 inch	2	001.698910
Pasta bowl deep 27 cm / 10.6 inch	2	001.698911
Soup plate with rim 23 cm / 9.1 inch	6	001.698900
Salad plate deep 19 cm / 7.4 inch	6	001.698909
Coupsoup 19 cm / 7.4 inch	6	001.698901
Soup cup 0,27 ltr. / 9.0 oz.	6	001.698904
Saucer 1 16 cm / 6.3 inch	6	001.698945
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.702211
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.698912
Bowl round 15 cm / 6.0 inch	4	001.698905
Bowl round 18 cm / 7.0 inch	2	001.698906
Bowl round 20 cm / 8.0 inch	2	001.698907
Bowl round 23 cm / 9.0 inch	2	001.698908
Oval platter 28 cm / 11.0 x 8.1 inch	2	001.698915
Oval platter 31 cm / 12.1 x 9.2 inch	2	001.698916
Oval platter 35 cm / 13.6 x 10.4 inch	2	001.698917
Soupbowl 0,50 ltr. / 16.7 oz.	6	001.706009
Plate flat 25,5 cm / 10.0 inch	6	001.706010



¹ PU = Packing Unit

² Item-No refers to undecorated articles





ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.173551
Tea pot 1 0,32 ltr. / 10.7 oz.	2	001.174553
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.175238
Sugar dish 8 cm / 3.2 inch	12	001.175066
Creamer 00 0,02 ltr. / 0.7 oz.	12	001.175911
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.176231
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.176561
Cup 5012 0,09 ltr. / 3.0 oz.	6	001.177213
Saucer 5012 12 cm / 4.7 inch	6	001.176734
Cup 5115 0,14 ltr. / 4.7 oz.	6	001.185818
Saucer 5115 13 cm / 5.3 inch	6	001.185647
Cup 5089 0,25 ltr. / 7.7 oz.	6	001.184484
Saucer 5089 14,7 cm / 5.8 inch	6	001.183983
Cup 5092 0,35 ltr. / 12.0 oz.	6	001.185156
Saucer 5092 15,9 cm / 6.3 inch	6	001.184815



ITEM DESCRIPTION	PU ¹	Item-No ²
Cup 1132 0,09 ltr. / 3.0 oz.	6	001.178516
Saucer 1132 11,8 cm / 4.6 inch	6	001.177855
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.188318
Saucer 1163 14,7 cm / 5.8 inch	6	001.187817
Cup 1131 0,22 ltr. / 7.3 oz.	6	001.186971
Saucer 1131 14,7 cm / 5.8 inch	6	001.186312
Cup 5118 0,29 ltr. / 9.7 oz.	6	001.658838
Saucer 5118 15,9 cm / 6.3 inch	6	001.658837
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.189312
Saucer 1164 15,9 cm / 6.3 inch	6	001.188651
Cup 5041 0,50 ltr. / 16.7 oz.	6	001.185487
Saucer 5041 19,1 cm / 7.5 inch	6	001.185327
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.185989
Mug with handle 5005 0,25 ltr. / 8.3 oz.	6	001.190944
Mug with handle 05 0,25 ltr. / 8.7 oz.	6	001.189972
Mug with handle 08 0,30 ltr. / 10.3 oz.	6	001.190132
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.189812
Cup 1 0,18 ltr. / 6.0 oz.	6	001.181815
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Cup 2 0,16 ltr. / 5.3 oz.	6	001.182624
Saucer 2 13,7 cm / 5.4 inch	6	001.182305
Cup 3 0,20 ltr. / 6.7 oz.	6	001.187484
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Cup 0,23 ltr. / 7.3 oz.	6	001.190624
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Cup 0,09 ltr. / 3.0 oz.	12	001.180662
Saucer 13,6 cm / 5.4 inch	12	001.180001
Cup high 0,08 ltr. / 2.7 oz.	12	001.179838
Saucer 13,6 cm / 5.4 inch	12	001.180001
Cup 0,25 ltr. / 8.3 oz.	6	001.183298
Saucer 1 16,2 cm / 6.4 inch	6	001.181154



¹ PU = Packing Unit

² Item-No refers to undecorated articles



MERAN

BASIC

ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 33 cm / 13.0 inch	6	001.157857
Plate flat with rim 30 cm / 12.0 inch	6	001.157014
Plate flat with rim 28 cm / 11.0 inch	6	001.156022
Plate flat with rim 26 cm / 10.2 inch	6	001.155188
Plate flat with rim 23 cm / 9.0 inch	6	001.154854
Plate flat with rim 20 cm / 8.0 inch	6	001.154013
Plate flat with rim 17 cm / 6.8 inch	6	001.153180
Plate flat with rim 15 cm / 6.0 inch	6	001.690815
Plate deep with rim 23 cm / 8.9 inch	6	001.160941
Pasta plate oval 32 cm / 12.6 x 10.3 inch	1	001.166267
Pasta plate 5009 30 cm / 11.8 inch	2	001.167730
Pasta plate 5064 27 cm / 10.6 inch	2	001.167068
Pasta plate 5008 23 cm / 9.0 inch	6	001.167388
Salad plate 19 cm / 7.6 inch	6	001.166589
Tureen 3,00 ltr. / 100.0 oz.	1	001.168093
Soup cup 0,28 ltr. / 9.3 oz.	6	001.162264
Saucer 1 16,2 cm / 6.4 inch	6	001.181154
Gravy boat 0,40 ltr. / 13.3 oz.	2	001.168255
Butter pad 0,04 ltr. / 1.3 oz.	2	001.168894
Gravy boat 0,10 ltr. / 3.3 oz.	4	001.169226

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl round 13 cm / 5.0 inch	6	001.162949
Bowl round 15 cm / 5.8 inch	4	001.163610
Bowl round 16 cm / 6.3 inch	2	001.164123
Bowl round 20 cm / 7.9 inch	2	001.164637
Bowl round 23 cm / 9.0 inch	2	001.165287
Bowl round 25 cm / 10.0 inch	2	001.165778
Oval plate flat 25 cm / 10.0 x 6.4 inch	2	001.171554
Oval plate flat 28 cm / 11.0 x 8.3 inch	2	001.172056
Oval plate flat 31 cm / 12.2 x 9.1 inch	2	001.172547
Oval plate flat 35 cm / 13.8 x 10.6 inch	2	001.173049
Vase	4	001.193048
Candleholder	2	001.194062
Ash tray	4	001.193730
Set salt and pepper	1	001.171063
Egg cup with rest	6	001.169716



¹ PU = Packing Unit

² Item-No refers to undecorated articles



ITEM DESCRIPTION

PU¹ Item-No²

Coup plate flat oval 5234 21 cm / 8.3 x 7.6 inch	6	001.004414
Coup plate flat oval 5195 25 cm / 9.8 x 9.0 inch	6	001.160460
Coup plate flat oval 5293 27 cm / 10.6 x 9.7 inch	6	001.159980
Coup plate flat oval 5192 29 cm / 11.9 x 11.0 inch	6	001.159500
Coup plate flat oval 5235 34 cm / 13.4 x 12.0 inch	2	001.004415
Fitness plate 5248 34 cm / 13.4 x 12.0 inch	2	001.659439
Fitness plate 5258 34 cm / 13.4 x 12.0 inch	2	001.705925
Coup plate flat 5196 15,5 cm / 6.2 inch	6	001.158540
Coup plate flat 5197 17,5 cm / 7.0 inch	6	001.159020
Coup plate flat round 5208 21,5 cm / 8.5 inch	6	001.618397
Coup plate flat round 5209 25,5 cm / 10.0 inch	6	001.618586
Coup plate flat round 5210 29 cm / 11.5 inch	6	001.618775
Coup plate deep 5236 14,5 cm / 5.7 inch	6	001.004416
Coup plate deep 5237 23 cm / 9.0 inch	6	001.004417
Coup plate deep 5211 29 cm / 11.6 inch	6	001.618964

ITEM DESCRIPTION

PU¹ Item-No²

Bowl 1060 0,60 ltr. / 20.0 oz.	6	001.004428
Bowl oval M5307 9 cm / 3.3 x 2.6 inch	6	001.722208
Bowl oval M5306 12 cm / 4.7 x 3.7 inch	6	001.722213
Soup bowl oval 5238 16 cm / 6.0 x 5.3 inch	4	001.004418
Bowl oval 5239 21 cm / 8.3 x 7.0 inch	2	001.004419
Bowl oval 5240 25,5 cm / 10.0 x 8.5 inch	2	001.004420
Oval platter deep 5231 18,5 cm / 7.2 x 4.7 inch	2	001.708948
Oval platter 5230 23,5 cm / 9.3 x 6.0 inch	2	001.708947
Cup 5241 0,09 ltr. / 3.0 oz.	6	001.004427
Saucer 5241 12,7 cm / 5.0 inch	6	001.004426
Cup 5242 0,20 ltr. / 6.7 oz.	6	001.004425
Saucer 5242 / 5243 16,2 cm / 6.4 inch	6	001.004424
Cup 5243 0,25 ltr. / 8.3 oz.	6	001.004423
Saucer 5242 / 5243 16,2 cm / 6.4 inch	6	001.004424
Mug Diva 5156 0,40 ltr. / 13.3 oz.	6	001.004429
Saucer 5156 17,5 cm / 7.0 inch	6	001.004421



¹ PU = Packing Unit

² Item-No refers to undecorated articles



	ITEM DESCRIPTION	PU ¹	Item-No ²
	Gourmet-plate flat organic M5340 34 cm / 13.4 x 11.0 inch	2	001.725323
	Gourmet-plate flat organic M5318 29,5 cm / 11.5 x 9.3 inch	6	001.725322
	Gourmet-plate flat organic M5319 24 cm / 9.4 x 7.7 inch	6	001.725321
	Gourmet-plate flat organic M5339 19 cm / 7.5 x 6.5 inch	6	001.725320
	Gourmet-bowl deep organic M5317 26 cm / 9.8 x 8.7 inch	2	001.725328
	Gourmet-bowl deep organic M5316 20 cm / 7.7 x 6.4 inch	2	001.725327
	Gourmet-bowl deep organic M5374 16 cm / 6.2 x 5.4 inch	4	001.725326
	Gourmet-bowl deep organic M5373 12 cm / 4.8 x 4.0 inch	6	001.725325
	Gourmet-bowl deep organic M5372 8 cm / 3.4 x 2.7 inch	6	001.725324

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Cup organic 0,21 ltr. / 7.0 oz.	6	001.725333
	Cup organic 0,28 ltr. / 9.5 oz.	6	001.725334
	Cup organic 0,37 ltr. / 12.3 oz.	6	001.725335
	Cup organic 0,22 ltr. / 7.3 oz.	6	001.725336
	Mug with handle organic 0,33 ltr. / 10.7 oz.	6	001.725341
	Saucer organic M5375 19 cm / 7.5 x 6.5 inch	6	001.725340
	Cup organic 0,11 ltr. / 3.7 oz.	6	001.725337
	Cup organic 0,16 ltr. / 5.3 oz.	6	001.725338
	Saucer organic M5376 15 cm / 6.0 x 5.2 inch	6	001.725339
	Sugar bowl with lid organic M5342 0,25 ltr. / 8.3 oz.	1	001.725329
	Creamer organic M5341 0,25 ltr. / 8.3 oz.	1	001.725332



¹ PU = Packing Unit

² Item-No refers to undecorated articles





ITEM DESCRIPTION	PU ¹	Item-No ²
Sugar bowl 0,28 ltr. / 9.3 oz.	1	001.015915
Creamer 0,25 ltr. / 8.3 oz.	1	001.015916
Cup 0,22 ltr. / 7.3 oz.	6	001.015918
Cup 0,23 ltr. / 8.3 oz.	6	001.015923
Cup 0,37 ltr. / 12.3 oz.	6	001.015922
Saucer round 17 cm / 6.7 inch	6	001.015927
Saucer square 19,5 x 16,5 cm / 7.8 x 6.5 inch	6	001.015928
Mug with handle 0,34 ltr. / 11.3 oz.	6	001.015924
Cup 5241* 0,09 ltr. / 3.0 oz.	6	001.659437
Cup 5242* 0,20 ltr. / 6.7 oz.	6	001.659436
Cup 5243* 0,25 ltr. / 8.3 oz.	6	001.659435
Saucer square Hotel** 19,5 cm / 7.8 x 6.5 inch	6	001.659434
Saucer square Hotel*** 16,0 cm / 6.3 x 5.3 inch	6	001.659433



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat square 30 x 26 cm / 11.7 x 10.3 inch	6	001.015900
Plate flat square 25 x 21 cm / 10.0 x 8.4 inch	6	001.015898
Plate flat square 20 x 16,5 cm / 7.8 x 6.5 inch	6	001.680985
Plate flat 28 cm / 11.0 inch	6	001.015894
Plate flat 23 cm / 9.0 inch	6	001.015897
Pasta plate deep 27 cm / 10.7 inch	2	001.015906
Plate deep 22,5 cm / 9.0 inch	6	001.015895
Bowl round 19 cm / 7.4 inch	6	001.015901
Plate 32 x 26,5 cm / 12.5 x 10.4 inch	1	001.015911
Bowl round 25 cm / 10.0 inch	1	001.015904
Bowl round 20 cm / 8.0 inch	1	001.015903
Bowl round 15 cm / 6.0 inch	2	001.015902
Gravy boat 0,55 ltr. / 18.3 oz.	1	001.015908



*Form Meran Steak & More

**fits with cup 5242 0,20 ltr. / 6.7 oz. and cup 5243 0,25 ltr. / 8.3 oz.

***fits with cup 5241 0,09 ltr. / 3.0 oz.

¹ PU = Packing Unit

² Item-No refers to undecorated articles





ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,34 ltr. / 11.3 oz.	2	001.606690
Coffee pot 3 0,66 ltr. / 22.0 oz.	2	001.607216
Tea pot 1 0,33 ltr. / 11.0 oz.	2	001.607901
Sugar bowl 2 0,20 ltr. / 6.7 oz.	1	001.608802
Creamer 0 0,04 ltr. / 1.3 oz.	12	001.609394
Creamer 1 0,15 ltr. / 5.0 oz.	1	001.609538
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.609754
Cup 1 0,18 ltr. / 6.0 oz.	6	001.611113
Saucer 1 14,5 cm / 5.7 inch	6	001.610860
Cup non stackable 0,22 ltr. / 7.3 oz.	6	001.613610
Saucer 1 14,5 cm / 5.7 inch	6	001.610860
Cup 0,09 ltr. / 3.0 oz.	12	001.610585
Saucer 12 cm / 4.7 inch	12	001.610333
Cup 0,25 ltr. / 8.3 oz.	6	001.612504
Saucer 1 14,5 cm / 5.7 inch	6	001.610860
Egg cup with rest	6	001.604695
Set salt and pepper	1	001.605538
Mug with handle 06 0,25 ltr. / 8.3 oz.	12	001.613256



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 30 cm / 12.0 inch	6	001.600942
Plate flat with rim 27 cm / 10.5 inch	6	001.600653
Plate flat with rim 25 cm / 9.8 inch	6	001.600365
Plate flat with rim 21 cm / 8.3 inch	6	001.600047
Plate flat with rim 19 cm / 7.5 inch	6	001.599759
Plate flat with rim 17 cm / 6.7 inch	6	001.599434
Plate flat with rim 15 cm / 6.0 inch	6	001.599318
Plate deep 23 cm / 9.0 inch	6	001.601325
Salad plate 19 cm / 7.5 inch	6	001.603822
Coupsoup 19 cm / 7.5 inch	6	001.601607
Pasta plate deep 30 cm / 11.9 inch	2	001.604031
Soup cup 0,28 ltr. / 9.3 oz.	6	001.602242
Saucer 16,2 cm / 6.4 inch	6	001.601953
Tureen 3,00 ltr. / 100.0 oz.	1	001.604126
Gravy boat 0,55 ltr. / 18.3 oz.	2	001.604270
Gravy boat 0,10 ltr. / 3.3 oz.	4	001.604515
Butter pad 0,06 ltr. / 2.0 oz.	2	001.604450
Bowl round 13 cm / 5.0 inch	6	001.602488
Bowl round 15 cm / 6.0 inch	4	001.602669
Bowl round 18 cm / 7.0 inch	2	001.602921
Bowl round 20 cm / 8.0 inch	2	001.603138
Bowl round 23 cm / 9.0 inch	2	001.603390
Bowl round 25 cm / 9.8 inch	2	001.603606
Oval platter 28 cm / 11.0 x 7.0 inch	2	001.605718
Oval platter 31 cm / 12.5 x 8.4 inch	2	001.605970
Oval platter 35 cm / 14.0 x 9.5 inch	2	001.606215
Oval platter 38 cm / 15.0 x 10.4 inch	2	001.606467
Oval platter 24 cm / 9.5 x 5.6 inch	2	001.604911
Candleholder 941	2	001.616203

¹ PU = Packing Unit

² Item-No refers to undecorated articles



C

UP FINE DINING

»FASHION«





C

COUP FINE DINING

»FASHION«

	ITEM DESCRIPTION	PU¹	Item-No	Airbrushed	Textured		ITEM DESCRIPTION	PU¹	Item-No	Airbrushed	Textured
	Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742473² 001.742515³	•			Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742478² 001.742520³	•	
	Tea pot 0,65 ltr. / 21.7 oz.	2	001.742484² 001.742526³	•			Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.742479² 001.742521³	•	
	Sugar bowl (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744627² 001.744634³	•			Saucer square small* M5387 13 x 13 cm 5.2 x 5.2 inch	6	001.742480² 001.742522³		•
	Creamer (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744628² 001.744635³	•			Saucer square big** M5387 16 x 16 cm 6.3 x 6.3 inch	6	001.742481² 001.742523³		•
							Saucer round small** M5390 13,5 cm / 5.2 inch	6	001.742482² 001.742524³		•
	Cup M5389 0,08 ltr. / 2.7 oz.	6	001.742474² 001.742516³	•			Saucer round big** M5390 16,5 cm / 6.5 inch	6	001.742483² 001.742525³		•
	Cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744625² 001.744632³	•			Showplate flat M5380 33 cm / 13.1 inch	4	001.742485² 001.742507³		•
	Cup M5389 0,19 ltr. / 6.3 oz.	6	001.742475² 001.742517³	•			Plate flat coup M5380 30 cm / 12.0 inch	6	001.742447² 001.742489³		•
	Cup M5389 0,22 ltr. / 7.3 oz.	6	001.742476² 001.742518³	•			Plate flat coup M5380 28 cm / 11.1 inch	6	001.742446² 001.742488³		•
	Cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.744626² 001.744633³	•			Plate flat coup M5380 26 cm / 10.3 inch	6	001.742445² 001.742487³		•
	Cup M5389 0,35 ltr. / 11.7 oz.	6	001.742477² 001.742519³	•			Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.742444² 001.742486³		•
							Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.742443² 001.742485³		•

C

UP FINE DINING

»FASHION«

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
Bowl coup M5381 28 cm / 11.0 inch	4	001.742462 ² 001.742504 ³	•	
Bowl coup M5381 26 cm / 10.3 inch	6	001.742461 ² 001.742503 ³	•	
Bowl coup M5381 23 cm / 9.2 inch	6	001.742460 ² 001.742502 ³	•	
Bowl coup M5381 20 cm / 7.9 inch	6	001.742459 ² 001.742501 ³	•	
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.742458 ² 001.742500 ³	•	
Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.742470 ² 001.742512 ³		•
Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.742466 ² 001.742508 ³		•
Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.742467 ² 001.742509 ³		•
Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.742469 ² 001.742511 ³		•
Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.742468 ² 001.742510 ³		•
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.742472 ² 001.742514 ³		•
Bowl high 0,18 ltr. / 6.3 oz.	6	001.742464 ² 001.742506 ³	•	
Bowl low 0,21 ltr. / 6.7 oz.	6	001.742463 ² 001.742505 ³	•	




* suitable for cup M5389 0,08 ltr. / 2.7 oz.,
cup 0,14 ltr. / 4.7 oz. (LIFE)

**suitable for all cups, except cup M5389 0,08 ltr. / 2.7 oz.,
cup 0,14 ltr. / 4.7 oz. (LIFE)

¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.742451 ² 001.742493 ³		•
Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.742450 ² 001.742492 ³		•
Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.742449 ² 001.742491 ³		•
Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.742448 ² 001.742490 ³		•
Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.742456 ² 001.742498 ³	•	
Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.742455 ² 001.742497 ³	•	
Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.742454 ² 001.742496 ³	•	
Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.742453 ² 001.742495 ³	•	
Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.742452 ² 001.742494 ³		•
Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.742457 ² 001.742499 ³	•	
Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.742471 ² 001.742513 ³		•
Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744622 ² 001.744629 ³	•	
Gravy boat (LIFE) 0,60 ltr. / 20.0 oz.	1	001.744623 ² 001.744630 ³	•	
Egg cup with rest (LIFE)	6	001.744624 ² 001.744631 ³	•	



² »old rose« 57270



³ »turquoise« 57271



C

UP FINE DINING

»FASHION«

ITEM DESCRIPTION PU¹ Item-No Airbrushed Textured

ITEM DESCRIPTION PU¹ Item-No Airbrushed Textured



Coffee pot 0,38 ltr. / 13.3 oz.	2	001.742557 ⁴ 001.742599 ⁵ 001.742641 ⁶	•	
Tea pot 0,65 ltr. / 21.7 oz.	2	001.742568 ⁴ 001.742610 ⁵ 001.742652 ⁶	•	
Sugar bowl 0,26 ltr. / 8.7 oz. (LIFE)	1	001.744641 ⁴ 001.744648 ⁵ 001.744655 ⁶	•	
Creamer 0,26 ltr. / 8.7 oz. (LIFE)	1	001.744642 ⁴ 001.744649 ⁵ 001.744656 ⁶	•	
Cup M5389 0,08 ltr. / 2.7 oz.	6	001.742558 ⁴ 001.742600 ⁵ 001.742642 ⁶	•	
Cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744639 ⁴ 001.744646 ⁵ 001.744653 ⁶	•	
Cup M5389 0,19 ltr. / 6.3 oz.	6	001.742559 ⁴ 001.742601 ⁵ 001.742643 ⁶	•	
Cup M5389 0,22 ltr. / 7.3 oz.	6	001.742560 ⁴ 001.742602 ⁵ 001.742644 ⁶	•	
Cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.744640 ⁴ 001.744647 ⁵ 001.744654 ⁶	•	
Cup M5389 0,35 ltr. / 11.7 oz.	6	001.742561 ⁴ 001.742603 ⁵ 001.742645 ⁶	•	



Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.742562 ⁴ 001.742604 ⁵ 001.742646 ⁶	•	
Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.742563 ⁴ 001.742605 ⁵ 001.742647 ⁶	•	
Saucer square small* M5387 13 x 13 cm 5.2 x 5.2 inch	6	001.742564 ⁴ 001.742606 ⁵ 001.742648 ⁶		•
Saucer square big** M5387 16 x 16 cm 6.3 x 6.3 inch	6	001.742565 ⁴ 001.742607 ⁵ 001.742649 ⁶		•
Saucer round small** M5390 13,5 cm / 5.2 inch	6	001.742566 ⁴ 001.742608 ⁵ 001.742650 ⁶		•
Saucer round big** M5390 16,5 cm / 6.5 inch	6	001.742567 ⁴ 001.742609 ⁵ 001.742651 ⁶		•
Showplate flat M5380 33 cm / 13.1 inch	4	001.742549 ⁴ 001.742591 ⁵ 001.742633 ⁶		•
Plate flat coup M5380 30 cm / 12.0 inch	6	001.742531 ⁴ 001.742573 ⁵ 001.742615 ⁶		•
Plate flat coup M5380 28 cm / 11.1 inch	6	001.742530 ⁴ 001.742572 ⁵ 001.742614 ⁶		•
Plate flat coup M5380 26 cm / 10.3 inch	6	001.742529 ⁴ 001.742571 ⁵ 001.742613 ⁶		•

C

COUP FINE DINING

»FASHION«

ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.742528 ⁴ 001.742570 ⁵ 001.742612 ⁶		●
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.742527 ⁴ 001.742569 ⁵ 001.742611 ⁶		●
Bowl coup M5381 28 cm / 11.0 inch	4	001.742546 ⁴ 001.742588 ⁵ 001.742630 ⁶	●	
Bowl coup M5381 26 cm / 10.3 inch	6	001.742545 ⁴ 001.742587 ⁵ 001.742629 ⁶	●	
Bowl coup M5381 23 cm / 9.2 inch	6	001.742544 ⁴ 001.742586 ⁵ 001.742628 ⁶	●	
Bowl coup M5381 20 cm / 7.9 inch	6	001.742543 ⁴ 001.742585 ⁵ 001.742627 ⁶	●	
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.742542 ⁴ 001.742584 ⁵ 001.742626 ⁶	●	
Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.742554 ⁴ 001.742596 ⁵ 001.742638 ⁶		●
Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.742550 ⁴ 001.742592 ⁵ 001.742634 ⁶		●
Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.742551 ⁴ 001.742593 ⁵ 001.742635 ⁶		●
Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.742553 ⁴ 001.742595 ⁵ 001.742637 ⁶		●
Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.742552 ⁴ 001.742594 ⁵ 001.742636 ⁶		●
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.742556 ⁴ 001.742598 ⁵ 001.742640 ⁶		●
Bowl high 0,18 ltr. / 6.3 oz.	6	001.742548 ⁴ 001.742590 ⁵ 001.742632 ⁶	●	
Bowl low 0,21 ltr. / 6.7 oz.	6	001.742547 ⁴ 001.742589 ⁵ 001.742631 ⁴	●	

* suitable for cup M5389 0,08 ltr. / 2.7 oz.,
cup 0,14 ltr. / 4.7 oz. (LIFE)

**suitable for all cups, except cup M5389 0,08 ltr. / 2.7 oz.,
cup 0,14 ltr. / 4.7 oz. (LIFE)

¹ PU = Packing Unit


ITEM DESCRIPTION	PU ¹	Item-No	Airbrushed	Textured
Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.742535 ⁴ 001.742577 ⁵ 001.742619 ⁶		●
Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.742534 ⁴ 001.742576 ⁵ 001.742618 ⁶		●
Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.742533 ⁴ 001.742575 ⁵ 001.742617 ⁶		●
Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.742532 ⁴ 001.742574 ⁵ 001.742616 ⁶		●
Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.742540 ⁴ 001.742582 ⁵ 001.742624 ⁶	●	
Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.742539 ⁴ 001.742581 ⁵ 001.742623 ⁶	●	
Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.742538 ⁴ 001.742580 ⁵ 001.742622 ⁶	●	
Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.742537 ⁴ 001.742579 ⁵ 001.742621 ⁶	●	
Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.742536 ⁴ 001.742578 ⁵ 001.742620 ⁶		●
Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.742541 ⁴ 001.742583 ⁵ 001.742625 ⁶	●	
Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.742555 ⁴ 001.742597 ⁵ 001.742639 ⁶		●
Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744636 ⁴ 001.744643 ⁵ 001.744650 ⁶	●	
Gravy boat 0,60 ltr. / 20.0 oz. (LIFE)	1	001.744637 ⁴ 001.744644 ⁵ 001.744651 ⁶	●	
Egg cup with rest (LIFE)	6	001.744638 ⁴ 001.744645 ⁵ 001.744652 ⁶	●	



⁴ »grey« 57272



⁵ »anthracite« 57273



⁶ »black« 57350



C

COUP FINE DINING

»KARMA« 57423

ITEM DESCRIPTION		PU¹	Item-No Karma 57423	Full decoration	Partial decoration
	Coffee pot 0,38 ltr. / 13.3 oz.	2	001.744569		●
	Tea pot 0,65 ltr. / 21.7 oz.	2	001.744570		●
	Sugar bowl (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744571		●
	Creamer (LIFE) 0,26 ltr. / 8.7 oz.	1	001.744572		●
	Cup M5389 0,08 ltr. / 2.7 oz.	6	001.744573		●
	Cup (LIFE) 0,14 ltr. / 4.7 oz.	6	001.744587		●
	Cup M5389 0,19 ltr. / 6.3 oz.	6	001.744574		●
	Cup M5389 0,22 ltr. / 7.3 oz.	6	001.744575		●
	Cup (LIFE) 0,28 ltr. / 9.3 oz.	6	001.744588		●
	Cup M5389 0,35 ltr. / 11.7 oz.	6	001.744576		●
ITEM DESCRIPTION		PU¹	Item-No Karma 57423	Full decoration	Partial decoration
	Mug with handle M5389 0,28 ltr. / 9.3 oz.	6	001.744577		●
	Mug with handle M5389 0,38 ltr. / 12.7 oz.	1	001.744578		●
	Saucer square small* M5387 13 x 13 cm 5.2 x 5.2 inch	6	001.744579	●	
	Saucer square big** M5387 16 x 16 cm 6.3 x 6.3 inch	6	001.744580	●	
	Saucer round small** M5390 13,5 cm / 5.2 inch	6	001.744581	●	
	Saucer round big** M5390 16,5 cm / 6.5 inch	6	001.744582	●	
	Showplate flat M5380 33 cm / 13.1 inch	4	001.744539	●	
	Plate flat coup M5380 30 cm / 12.0 inch	6	001.744540	●	
	Plate flat coup M5380 28 cm / 11.1 inch	6	001.744541	●	
	Plate flat coup M5380 26 cm / 10.3 inch	6	001.744542	●	

C OUP FINE DINING

»KARMA« 57423

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.744543	●	
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.744544	●	
 Bowl coup M5381 28 cm / 11.0 inch	4	001.744545		●
Bowl coup M5381 26 cm / 10.3 inch	6	001.744546		●
Bowl coup M5381 23 cm / 9.2 inch	6	001.744547		●
Bowl coup M5381 20 cm / 7.9 inch	6	001.744548		●
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.744549		●
 Platter coup M5379 33 x 18 cm 13.0 x 7.0 inch	2	001.744550	●	
Platter coup M5379 40 x 25,5 cm 15.9 x 10.2 inch	2	001.744551	●	
Platter coup M5379 43 x 19 cm 17.1 x 7.5 inch	2	001.744552	●	
Platter coup M5379 35 x 11 cm 13.9 x 4.5 inch	2	001.744553	●	
Platter coup M5379 44 x 14 cm 17.4 x 5.6 inch	2	001.744554	●	
 Setplatter 44 cm 17.5 x 5.6 inch	2	001.744555	●	
 Bowl high 0,18 ltr. / 6.3 oz.	6	001.744556		●
 Bowl low 0,21 ltr. / 6.7 oz.	6	001.744557		●

ITEM DESCRIPTION	PU ¹	Item-No Karma 57423	Full decoration	Partial decoration
 Plate flat coup square M5383 29 x 29 cm 11.5 x 11.5 inch	4	001.744558	●	
Plate flat coup square M5383 26 x 26 cm 10.2 x 10.2 inch	6	001.744559	●	
Plate flat coup square M5383 22 x 22 cm 8.7 x 8.7 inch	6	001.744560	●	
Plate flat coup square M5383 16,5 x 16,5 cm 6.5 x 6.5 inch	6	001.744561	●	
 Bowl coup square M5384 26 x 26 cm 10.2 x 10.2 inch	4	001.744562		●
Bowl coup square M5384 22 x 22 cm 8.6 x 8.6 inch	6	001.744563		●
Bowl coup square M5384 17,5 x 17,5 cm 6.9 x 6.9 inch	6	001.744564		●
 Bowl coup square M5384 13 x 13 cm 5.0 x 5.0 inch	6	001.744565		●
 Plate flat coup rectangular M5385 35 x 20 cm 14.0 x 8.0 inch	2	001.744566	●	
 Bowl coup rectangular M5386 25,5 x 18 cm 10.2 x 7.0 inch	2	001.744567		●
 Platter coup rectangular M5388 38 x 14 cm 15.2 x 5.6 inch	2	001.744568	●	
 Tureen with lid 3,00 ltr. / 100.0 oz. (LIFE)	1	001.744584		●
 Gravy boat 0,60 ltr. / 20.0 oz. (LIFE)	1	001.744585		●
 Egg cup with rest (LIFE)	6	001.744586	●	



- 2 Full decoration
3 Partial decoration

* suitable for cup M5389 0,08 ltr. / 2.7 oz.,
cup 0,14 ltr. / 4.7 oz. (LIFE)

**suitable for all cups, except cup M5389 0,08 ltr. / 2.7 oz.,
cup 0,14 ltr. / 4.7 oz. (LIFE)


¹ PU = Packing Unit



C

COUP FINE DINING

»FANTASTIC«

ITEM DESCRIPTION	PU ¹	Item-No	ITEM DESCRIPTION	PU ¹	Item-No
 Showplate flat M5380 33 cm / 13.0 inch	4	001.736067 ² 001.736071 ³ 001.736075 ⁴ 001.736079 ⁵ 001.749512 ⁶	 Bowl coup M5381 28 cm / 11.0 inch	4	001.736066 ² 001.736070 ³ 001.736074 ⁴ 001.736078 ⁵ 001.749518 ⁶
 Plate flat coup M5380 30 cm / 12.0 inch	6	001.736065 ² 001.736069 ³ 001.736073 ⁴ 001.736077 ⁵ 001.749513 ⁶	 Bowl coup M5381 26 cm / 10.3 inch	6	001.736286 ² 001.736316 ³ 001.736346 ⁴ 001.736376 ⁵ 001.749519 ⁶
 Plate flat coup M5380 28 cm / 11.0 inch	6	001.736282 ² 001.736312 ³ 001.736342 ⁴ 001.736372 ⁵ 001.749514 ⁶	 Bowl coup M5381 23 cm / 9.2 inch	6	001.736285 ² 001.736315 ³ 001.736345 ⁴ 001.736375 ⁵ 001.749520 ⁶
 Plate flat coup M5380 26 cm / 10.3 inch	6	001.736064 ² 001.736068 ³ 001.736072 ⁴ 001.736076 ⁵ 001.749515 ⁶	 Bowl coup M5381 20 cm / 7.9 inch	6	001.736284 ² 001.736314 ³ 001.736344 ⁴ 001.736374 ⁵ 001.749521 ⁶
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.736281 ² 001.736311 ³ 001.736341 ⁴ 001.736371 ⁵ 001.749516 ⁶	 Bowl coup M5381 14,5 cm / 5.7 inch	6	001.736283 ² 001.736313 ³ 001.736343 ⁴ 001.736373 ⁵ 001.749522 ⁶
 Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.736280 ² 001.736310 ³ 001.736340 ⁴ 001.736370 ⁵ 001.749517 ⁶			[2] »royal blue« 57122 [3] »turquoise« 57123 [4] »grey« 57124 [5] »caramel« 57125 [6] »brick red« 57126

C

COUP FINE DINING

»FANTASTIC«

	ITEM DESCRIPTION	PU ¹	Item-No
	Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.736293 ² 001.736323 ³ 001.736353 ⁴ 001.736383 ⁵ 001.749523 ⁶
	Platter coup M5379 40 x 25,5 cm / 16.0 x 10.2 inch	2	001.736289 ² 001.736319 ³ 001.736349 ⁴ 001.736379 ⁵ 001.749524 ⁶
	Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.736290 ² 001.736320 ³ 001.736350 ⁴ 001.736380 ⁵ 001.749525 ⁶
	Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.736292 ² 001.736322 ³ 001.736352 ⁴ 001.736382 ⁵ 001.749526 ⁶
	Platter coup M5379 44 x 14 cm / 17.3 x 5.6 inch	2	001.736291 ² 001.736321 ³ 001.736351 ⁴ 001.736381 ⁵ 001.749527 ⁶
	Setplatter 44 cm / 17.5 x 5.6 inch	2	001.736294 ² 001.736324 ³ 001.736354 ⁴ 001.736384 ⁵ 001.749528 ⁶
	Bowl high 0,18 ltr. / 6.3 oz.	6	001.736288 ² 001.736318 ³ 001.736348 ⁴ 001.736378 ⁵ 001.749529 ⁶
	Bowl low 0,21 ltr. / 6.6 oz.	6	001.736287 ² 001.736317 ³ 001.736347 ⁴ 001.736377 ⁵ 001.749530 ⁶
	Foodbowl 13 cm	4	001.757112 ² 001.757117 ³ 001.757122 ⁴ 001.757127 ⁵ 001.757132 ⁶
	Foodbowl 17,5 cm	2	001.757113 ² 001.757118 ³ 001.757123 ⁴ 001.757128 ⁵ 001.757133 ⁶
	Foodbowl 20 cm	2	001.757114 ² 001.757119 ³ 001.757124 ⁴ 001.757129 ⁵ 001.757134 ⁶
	Foodbowl 25 cm	2	001.757115 ² 001.757120 ³ 001.757125 ⁴ 001.757130 ⁵ 001.757135 ⁶
	Foodbowl 28 cm	2	001.757116 ² 001.757121 ³ 001.757126 ⁴ 001.757131 ⁵ 001.757136 ⁶

¹ PU = Packing Unit

	ITEM DESCRIPTION	PU ¹	Item-No
	Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.736295 ² 001.736325 ³ 001.736355 ⁴ 001.736385 ⁵ 001.749531 ⁶
	Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.736296 ² 001.736326 ³ 001.736356 ⁴ 001.736386 ⁵ 001.749532 ⁶
	Creamer 2 0,23 ltr. / 7.7 oz.	1	001.736297 ² 001.736327 ³ 001.736357 ⁴ 001.736387 ⁵ 001.749533 ⁶
	Cup 1132 0,09 ltr. / 3.0 oz.	6	001.736299 ² 001.736329 ³ 001.736359 ⁴ 001.736389 ⁵ 001.749535 ⁶
	Saucer 1132 11,8 cm / 4.7 inch	6	001.736298 ² 001.736328 ³ 001.736358 ⁴ 001.736388 ⁵ 001.749534 ⁶
	Cup 1163 0,18 ltr. / 6.0 oz.	6	001.736304 ² 001.736334 ³ 001.736364 ⁴ 001.736394 ⁵ 001.749536 ⁶
	Saucer 1163 14,7 cm / 5.8 inch	6	001.736303 ² 001.736333 ³ 001.736363 ⁴ 001.736393 ⁵ 001.749537 ⁶
	Cup 1131 0,22 ltr. / 7.3 oz.	6	001.736302 ² 001.736332 ³ 001.736362 ⁴ 001.736392 ⁵ 001.749538 ⁶
	Saucer 1131 14,7 cm / 5.8 inch	6	001.736301 ² 001.736331 ³ 001.736361 ⁴ 001.736391 ⁵ 001.749539 ⁶
	Cup 1164 0,37 ltr. / 12.3 oz.	6	001.736306 ² 001.736336 ³ 001.736366 ⁴ 001.736396 ⁵ 001.749540 ⁶
	Saucer 1164 15,9 cm / 6.3 inch	6	001.736305 ² 001.736335 ³ 001.736365 ⁴ 001.736395 ⁵ 001.749541 ⁶
	Cup 5041 without handle 0,50 ltr. / 16.7 oz.	6	001.736300 ² 001.736330 ³ 001.736360 ⁴ 001.736390 ⁵ 001.749542 ⁶
	Mug with handle 5005 0,25 ltr. / 8.3 oz. non stackable	6	001.736307 ² 001.736337 ³ 001.736367 ⁴ 001.736397 ⁵ 001.749543 ⁶
	Mug with handle 5025 0,40 ltr. / 13.3 oz. non stackable	6	001.736308 ² 001.736338 ³ 001.736368 ⁴ 001.736398 ⁵ 001.749544 ⁶



BUFFET GOURMET

»FANTASTIC«

ITEM DESCRIPTION			PU ¹	Item-No	ITEM DESCRIPTION			PU ¹	Item-No
	Bowl 5140 15 x 15 cm / 6.0 x 6.0 inch		2	001.736096 ² 001.736128 ³ 001.736158 ⁴ 001.736188 ⁵ 001.749476 ⁶		Dressing pot without lid 5140 1,00 ltr. / 33.3 oz.		1	001.736100 ² 001.736132 ³ 001.736162 ⁴ 001.736192 ⁵ 001.749482 ⁶
	Bowl 5140 20 x 20 cm / 8.0 x 8.0 inch		1	001.736097 ² 001.736129 ³ 001.736159 ⁴ 001.736189 ⁵ 001.749477 ⁶		Platter 5170 16 x 16 cm / 6.3 x 6.3 inch		2	001.736101 ² 001.736133 ³ 001.736163 ⁴ 001.736193 ⁵ 001.749483 ⁶
	Bowl 5140 26 x 26 cm / 10.3 x 10.3 inch		1	001.736098 ² 001.736130 ³ 001.736160 ⁴ 001.736190 ⁵ 001.749478 ⁶		Platter 5170 23 x 23 cm / 9.0 x 9.0 inch		1	001.736102 ² 001.736134 ³ 001.736164 ⁴ 001.736194 ⁵ 001.749484 ⁶
	Bowl 5160 25 x 25 x 7 cm / 9.9 x 9.9 inch		1	001.737860 ² 001.737861 ³ 001.737862 ⁴ 001.737863 ⁵ 001.749479 ⁶		Platter 5170 32,5 x 22,4 cm / 12.8 x 4.3 inch		1	001.736103 ² 001.736135 ³ 001.736165 ⁴ 001.736195 ⁵ 001.749485 ⁶
	Bowl 5180 35 x 35 x 5 cm / 13.8 x 13.8 inch		1	001.737864 ² 001.737865 ³ 001.737866 ⁴ 001.737867 ⁵ 001.749480 ⁶		Platter 5170 32,5 x 10,8 cm / 12.8 x 8.8 inch		1	001.736104 ² 001.736136 ³ 001.736166 ⁴ 001.736196 ⁵ 001.749486 ⁶
	Dessing pot without lid 5140 1,50 ltr. / 50.0 oz.		1	001.736099 ² 001.736131 ³ 001.736161 ⁴ 001.736191 ⁵ 001.749481 ⁶		Platter 5170 32,5 x 32,5 cm / 12.8 x 12.8 inch		1	001.736105 ² 001.736137 ³ 001.736167 ⁴ 001.736197 ⁵ 001.749487 ⁶

¹ PU = Packing Unit

* fits: cooling tray stainless steel 7 inch

BUFFET GOURMET

»FANTASTIC«

	ITEM DESCRIPTION	PU ¹	Item-No
	GN Platter 5170-1/1 53 x 32,5 cm / 20.8 x 12.8 inch	1	001.736106 ² 001.736138 ³ 001.736168 ⁴ 001.736198 ⁵ 001.749488 ⁶
	GN Platter 5170-1/2 32,5 x 26,5 cm / 12.8 x 10.4 inch	2	001.736107 ² 001.736139 ³ 001.736169 ⁴ 001.736199 ⁵ 001.749489 ⁶
	GN Platter 5170-1/3 32,5 x 17,6 cm / 12.8 x 7.0 inch	3	001.736108 ² 001.736140 ³ 001.736170 ⁴ 001.736200 ⁵ 001.749490 ⁶
	GN Platter 5170-2/4 53 x 16,2 cm / 20.8 x 6.4 inch	2	001.736109 ² 001.736141 ³ 001.736171 ⁴ 001.736201 ⁵ 001.749491 ⁶
	Platter round 5120* 18 cm / 9.0 inch	1	001.736110 ² 001.736142 ³ 001.736172 ⁴ 001.736202 ⁵ 001.749492 ⁶
	Bowl 5140 6 x 6 cm / 2.3 x 2.3 inch	6	001.736111 ² 001.736143 ³ 001.736173 ⁴ 001.736203 ⁵ 001.749493 ⁶
	Bowl 5140 10 x 10 cm / 3.9 x 3.9 inch	2	001.736112 ² 001.736144 ³ 001.736174 ⁴ 001.736204 ⁵ 001.749494 ⁶
	Bowl 5120 - 28/11 28 cm / 11.0 inch	1	001.736113 ² 001.736145 ³ 001.736175 ⁴ 001.736205 ⁵ 001.749495 ⁶
	Bowl with cover 5120 0,50 ltr. / 23.3 oz.	1	001.736114 ² 001.736146 ³ 001.736176 ⁴ 001.736206 ⁵ 001.749496 ⁶
	Bowl without cover 5120 0,50 ltr. / 23.3 oz.	1	001.736115 ² 001.736147 ³ 001.736177 ⁴ 001.736207 ⁵ 001.749497 ⁶
	Cover for bowl 5120 8 cm / 3.3 inch	1	001.736116 ² 001.736148 ³ 001.736178 ⁴ 001.736208 ⁵ 001.749498 ⁶
	Bowl with cover 5120 1,50 ltr. / 63.3 oz.	1	001.736117 ² 001.736149 ³ 001.736179 ⁴ 001.736209 ⁵ 001.749499 ⁶
	Bowl without cover 5120 1,50 ltr. / 63.3 oz.	1	001.736118 ² 001.736150 ³ 001.736180 ⁴ 001.736210 ⁵ 001.749500 ⁶
	Cover for bowl 5120 11 cm / 4.3 inch	1	001.736119 ² 001.736151 ³ 001.736181 ⁴ 001.736211 ⁵ 001.749501 ⁶

	ITEM DESCRIPTION	PU ¹	Item-No
	Bowl with cover 5120 3,50 ltr. / 150.0 oz.	1	001.736120 ² 001.736152 ³ 001.736182 ⁴ 001.736212 ⁵ 001.749502 ⁶
	Bowl without cover 5120 3,50 ltr. / 150.0 oz.	1	001.736121 ² 001.736153 ³ 001.736183 ⁴ 001.736213 ⁵ 001.749503 ⁶
	Cover for bowl 5120 17 cm / 6.7 inch	1	001.736122 ² 001.736154 ³ 001.736184 ⁴ 001.736214 ⁵ 001.749504 ⁶
	Bowl with cover 5140 2,00 ltr. / 66.6 oz.	1	001.736123 ² 001.736155 ³ 001.736185 ⁴ 001.736215 ⁵ 001.749505 ⁶
	Bowl without cover 5140 2,00 ltr. / 66.6 oz.	1	001.736124 ² 001.736156 ³ 001.736186 ⁴ 001.736216 ⁵ 001.749506 ⁶
	Cover for bowl 5140 19,5 cm / 7.7 inch	1	001.736125 ² 001.736157 ³ 001.736187 ⁴ 001.736217 ⁵ 001.749507 ⁶
	Bowl sloping 8,5 cm / 3.4 inch (SAVOY)	6	001.736080 ² 001.736084 ³ 001.736088 ⁴ 001.736092 ⁵ 001.749508 ⁶
	Bowl sloping 11 cm / 4.4 inch (SAVOY)	6	001.736083 ² 001.736087 ³ 001.736091 ⁴ 001.736095 ⁵ 001.749509 ⁶
	Bowl square 9 cm / 3.5 x 3.5 inch (SAVOY)	6	001.736081 ² 001.736085 ³ 001.736089 ⁴ 001.736093 ⁵ 001.749510 ⁶
	Bowl square 11 cm / 4.8 x 4.8 inch (SAVOY)	6	001.736082 ² 001.736086 ³ 001.736090 ⁴ 001.736094 ⁵ 001.749511 ⁶



2 »royal blue« 57122
3 »turquoise« 57123
4 »grey« 57124
5 »caramel« 57125
6 »brick red« 57126



C

COUP FINE DINING

»COUNTRY LIFE«

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.731546 ² 001.731560 ³
Plate flat coup M5380 30 cm / 12.0 inch	6	001.731540 ² 001.731554 ³
Plate flat coup M5380 28 cm / 11.1 inch	6	001.731539 ² 001.731553 ³
Plate flat coup M5380 26 cm / 10.3 inch	6	001.731538 ² 001.731552 ³
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731537 ² 001.731551 ³
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731536 ² 001.731550 ³
Bowl coup M5381 28 cm / 11.0 inch	4	001.731545 ² 001.731559 ³
Bowl coup M5381 26 cm / 10.3 inch	6	001.731544 ² 001.731558 ³
Bowl coup M5381 23 cm / 9.2 inch	6	001.731543 ² 001.731557 ³
Bowl coup M5381 20 cm / 7.9 inch	6	001.731542 ² 001.731556 ³
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731541 ² 001.731555 ³
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733793 ² 001.733795 ³
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731547 ² 001.731561 ³
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731548 ² 001.731562 ³
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733792 ² 001.733794 ³
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731549 ² 001.731563 ³
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732812 ² 001.732815 ³
Bowl high 0,18 ltr. / 6.3 oz.	6	001.732811 ² 001.732814 ³
Bowl low 0,21 ltr. / 6.7 oz.	6	001.732810 ² 001.732813 ³

¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.731968 ² 001.731991 ³
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.731969 ² 001.731992 ³
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.731970 ² 001.731993 ³
Cup 1132 0,09 ltr. / 3.0 oz.	6	001.731972 ² 001.731995 ³
Saucer 1132 11,8 cm / 4.7 inch	6	001.731971 ² 001.731994 ³
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.731977 ² 001.732001 ³
Saucer 1163 14,7 cm / 5.8 inch	6	001.731976 ² 001.731999 ³
Cup 1131 0,22 ltr. / 7.3 oz.	6	001.731975 ² 001.731998 ³
Saucer 1131 14,7 cm / 5.8 inch	6	001.731974 ² 001.731997 ³
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.731979 ² 001.732003 ³
Saucer 1164 15,9 cm / 6.3 inch	6	001.731978 ² 001.732002 ³
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.731973 ² 001.731996 ³
Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.731989 ² 001.732004 ³
Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.731990 ² 001.732005 ³



[2] »champagne« 5/010

[3] »petrol« 57011



C

COUP FINE DINING

»COUNTRY LIFE«

ITEM DESCRIPTION	PU¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.731574 ⁴ 001.731588 ⁵
Plate flat coup M5380 30 cm / 12.0 inch	6	001.731568 ⁴ 001.731582 ⁵
Plate flat coup M5380 28 cm / 11.1 inch	6	001.731567 ⁴ 001.731581 ⁵
Plate flat coup M5380 26 cm / 10.3 inch	6	001.731566 ⁴ 001.731580 ⁵
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731565 ⁴ 001.731579 ⁵
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731564 ⁴ 001.731578 ⁵
Bowl coup M5381 28 cm / 11.0 inch	4	001.731573 ⁴ 001.731587 ⁵
Bowl coup M5381 26 cm / 10.3 inch	6	001.731572 ⁴ 001.731586 ⁵
Bowl coup M5381 23 cm / 9.2 inch	6	001.731571 ⁴ 001.731585 ⁵
Bowl coup M5381 20 cm / 7.9 inch	6	001.731570 ⁴ 001.731584 ⁵
Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731569 ⁴ 001.731583 ⁵
Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733797 ⁴ 001.733799 ⁵
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731575 ⁴ 001.731589 ⁵
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731576 ⁴ 001.731590 ⁵
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733796 ⁴ 001.733798 ⁵
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731577 ⁴ 001.731591 ⁵
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732818 ⁴ 001.732821 ⁵
Bowl high 0,18 ltr. / 6.3 oz.	6	001.732817 ⁴ 001.732820 ⁵
Bowl low 0,21 ltr. / 6.7 oz.	6	001.732816 ⁴ 001.732819 ⁵

¹ PU = Packing Unit

ITEM DESCRIPTION	PU¹	Item-No
Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.732006 ⁴ 001.732020 ⁵
Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.732007 ⁴ 001.732021 ⁵
Creamer 2 0,23 ltr. / 7.7 oz.	1	001.732008 ⁴ 001.732022 ⁵
Cup 1132 0,09 ltr. / 3.0 oz.	6	001.732010 ⁴ 001.732024 ⁵
Saucer 1132 11,8 cm / 4.7 inch	6	001.732009 ⁴ 001.732023 ⁵
Cup 1163 0,18 ltr. / 6.0 oz.	6	001.732015 ⁴ 001.732029 ⁵
Saucer 1163 14,7 cm / 5.8 inch	6	001.732014 ⁴ 001.732028 ⁵
Cup 1131 0,22 ltr. / 7.3 oz.	6	001.732013 ⁴ 001.732027 ⁵
Saucer 1131 14,7 cm / 5.8 inch	6	001.732012 ⁴ 001.732026 ⁵
Cup 1164 0,37 ltr. / 12.3 oz.	6	001.732017 ⁴ 001.732031 ⁵
Saucer 1164 15,9 cm / 6.3 inch	6	001.732016 ⁴ 001.732030 ⁵
Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.732011 ⁴ 001.732025 ⁵
Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.732018 ⁴ 001.732032 ⁵
Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.732019 ⁴ 001.732033 ⁵



[4] »olive« 57012

[5] »terracotta« 57013



2 »Reflections« 57514

3 »Growth« 57516

4 »Oak« 57654



C OUP FINE DINING

»REFLECTIONS« | »GROWTH« | »OAK«

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.749606 ² 001.749585 ³ 001.755030 ⁴
Plate flat coup M5380 30 cm / 12.0 inch	6	001.749607 ² 001.749586 ³ 001.755031 ⁴
Plate flat coup M5380 28 cm / 11.1 inch	6	001.749608 ² 001.749587 ³ 001.755032 ⁴
Plate flat coup M5380 26 cm / 10.3 inch	6	001.749609 ² 001.749588 ³ 001.755033 ⁴
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.749610 ² 001.749589 ³ 001.755034 ⁴
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.749611 ² 001.749590 ³ 001.755035 ⁴
Bowl coup M5381 28 cm / 11.0 inch	4	001.749612 ² 001.749591 ³ 001.755036 ⁴
Bowl coup M5381 26 cm / 10.3 inch	6	001.749613 ² 001.749592 ³ 001.755037 ⁴
Bowl coup M5381 23 cm / 9.2 inch	6	001.749614 ² 001.749593 ³ 001.755038 ⁴

ITEM DESCRIPTION	PU ¹	Item-No
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.749615 ² 001.749594 ³ 001.755039 ⁴
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.749616 ² 001.749595 ³ 001.755040 ⁴
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.749617 ² 001.749596 ³ 001.755041 ⁴
Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.749618 ² 001.749597 ³ 001.755042 ⁴
Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.749619 ² 001.749598 ³ 001.755043 ⁴
Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.749620 ² 001.749599 ³ 001.755044 ⁴
Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.749621 ² 001.749600 ³ 001.755045 ⁴
Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.749622 ² 001.749601 ³ 001.755046 ⁴
Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.749623 ² 001.749602 ³ 001.755047 ⁴
Plate flat coup rectangular 35 x 20 cm / M5385 14.0 x 8.0 inch	2	001.749624 ² 001.749603 ³ 001.755048 ⁴
Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.749625 ² 001.749604 ³ 001.755049 ⁴
Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.749626 ² 001.749605 ³ 001.755050 ⁴



¹ PU = Packing Unit





C OUP FINE DINING

»BLUE SEA« 57515

ITEM DESCRIPTION	PU ¹	Item-No
Showplate flat M5380 33 cm / 13.1 inch	4	001.749686
Plate flat coup M5380 30 cm / 12.0 inch	6	001.749687
Plate flat coup M5380 28 cm / 11.1 inch	6	001.749688
Plate flat coup M5380 26 cm / 10.3 inch	6	001.749689
Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.749690
Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.749691
Bowl coup M5381 28 cm / 11.0 inch	4	001.749692
Bowl coup M5381 26 cm / 10.3 inch	6	001.749693
Bowl coup M5381 23 cm / 9.2 inch	6	001.749694

ITEM DESCRIPTION	PU ¹	Item-No
Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.749695
Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.749696
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.749697
Plate flat coup square M5383 29 x 29 cm / 11.5 x 11.5 inch	4	001.749700
Plate flat coup square M5383 26 x 26 cm / 10.3 x 10.3 inch	6	001.749702
Plate flat coup square M5383 22 x 22 cm / 8.6 x 8.6 inch	6	001.749703
Plate flat coup square M5383 16,5 x 16,5 cm / 6.5 x 6.5 inch	6	001.749705
Bowl coup square M5384 26 x 26 cm / 10.0 x 10.0 inch	4	001.749706
Bowl coup square M5384 22 x 22 cm / 8.6 x 8.6 inch	6	001.749708
Plate flat coup rectangular 35 x 20 cm / M5385 14.0 x 8.0 inch	2	001.949709
Bowl coup rectangular M5386 25,5 x 18 cm / 10.0 x 7.0 inch	2	001.749710
Platter coup rectangular M5388 38 x 14 cm / 15.0 x 6.6 inch	2	001.749711



¹ PU = Packing Unit



BUFFET GOURMET

ITEM DESCRIPTION	PU ¹	Item-No ²
Platter rect. 5140 16 x 16 cm / 6.2 x 6.2 inch	2	001.590330
Platter rect. 5140 25 x 25 cm / 10.0 x 10.0 inch	2	001.590405
Platter rect. 5140 25 x 14 cm / 10.0 x 5.6 inch	2	001.591283
Platter rect. 5140 35 x 14 cm / 14.0 x 5.6 inch	1	001.590505
Platter rect. 5140 35 x 25 cm / 14.0 x 10.0 inch	1	001.590530
Platter rect. 5140 35 x 35 cm / 14.0 x 14.0 inch	1	001.590580
Bowl 5140 11 x 11 cm / 4.3 x 4.3 inch	4	001.588734
Bowl 5140 15 x 15 cm / 6.0 x 6.0 inch	2	001.590205
Bowl 5140 17 x 17 cm / 6.6 x 6.6 inch	2	001.588759
Bowl 5140 20 x 20 cm / 8.0 x 8.0 inch	1	001.590255
Bowl 5140 23 x 23 cm / 9.0 x 9.0 inch	1	001.590630
Bowl 5140 26 x 26 cm / 10.2 x 10.2 inch	1	001.590655
Bowl 5140 6 x 6 cm / 2.4 x 2.4 inch	6	001.591508
Bowl 5140 10 x 10 cm / 4.0 x 4.0 inch	2	001.590680
Bowl 5140 10 x 20 cm / 8.0 x 4.0 inch	2	001.591583
Bowl 5140 5 x 20 cm / 8.0 x 2.0 inch	1	001.590105
Bowl 5140 5 x 30 cm / 12.0 x 2.0 inch	1	001.590155
Dressing pot 5140 1,50 ltr. / 50.0 oz.	1	001.589924
Dressing pot 5140 1,00 ltr. / 33.3 oz.	1	001.591458
Dressing pot 5140	12	001.591483

ITEM DESCRIPTION	PU ¹	Item-No ²
Bowl 5160 25 x 25 x 7 cm / 10.0 x 10.0 inch	2	001.589543
Bowl 5160 20 x 20 x 7 cm / 8.0 x 8.0 inch	2	001.589493
Bowl 5160 16 x 16 x 7 cm / 6.2 x 6.2 inch	1	001.589468
Bowl 5160 10 x 20 x 7 cm / 8.0 x 4.0 inch	1	001.589443
Bowl 5160 10 x 10 x 7 cm / 4.0 x 4.0 inch	1	001.737676
Platter rect. 5170 10 x 10 cm / 4.0 x 4.0 inch	2	001.589593
Platter rect. 5170 10 x 20 cm / 8.0 x 4.0 inch	2	001.589646
Platter rect. 5170 16 x 16 cm / 6.2 x 6.2 inch	2	001.589771
Platter rect. 5170 20 x 20 cm / 8.0 x 8.0 inch	2	001.589696
Platter rect. 5170 23 x 23 cm / 9.0 x 9.0 inch	1	001.659426
Platter rect. 5170 32,5 x 10,8 cm / 12.7 x 4.2 inch	1	001.659427
Platter rect. 5170 32,5 x 22,4 cm / 12.7 x 8.8 inch	1	001.659428
Platter rect. 5170 32,5 x 32,5 cm / 12.7 x 12.7 inch	1	001.659429
GN-Platter 5170-1/1 53 x 32,5 cm / 20.8 x 12.7 inch	1	001.700086
GN-Platter 5170-1/2 32,5 x 26,5 cm / 12.7 x 10.4 inch	2	001.700087
GN-Platter 5170-1/3 32,5 x 17,6 cm / 12.7 x 7.0 inch	3	001.700088
GN-Platter 5170-2/4 53 x 16,2 cm / 20.8 x 6.3 inch	2	001.700089
Bowl 5180 10 x 10 x 5 cm / 4.0 x 4.0 inch	4	001.590002
Bowl 5180 16 x 16 x 5 cm / 6.2 x 6.2 inch	1	001.589949
Bowl 5180 35 x 35 x 5 cm / 14.0 x 14.0 inch	1	001.737677



¹ PU = Packing Unit

² Item-No refers to undecorated articles





BUFFET GOURMET

ITEM DESCRIPTION

PU¹ Item-No²

Bowl 5120-18/8 18 cm / 7.0 inch	4	001.682250
Bowl 5120-24/11 24 cm / 9.4 inch	2	001.682251
Bowl 5120-28/11 28 cm / 11.0 inch	1	001.590305
Bowl 5120-30/15 30 cm / 12.0 inch	1	001.590280
Bowl with lid 5120 0,50 ltr. / 23.3 oz.	1	001.656976
Bowl with lid 5120 1,50 ltr. / 63.3 oz.	1	001.656985
Bowl with lid 5120 3,50 ltr. / 150.0 oz.	1	001.656994
Bowl with lid 5140 2,00 ltr. / 66.7 oz.	1	001.686852
Bowl without lid 5140 2,00 ltr. / 66.7 oz.	1	001.588634
Baker oval 22 x 14,5 cm / 8.7 x 5.7 inch (LUKULLUS)	1	001.103257
Roaster rectangular (LUKULLUS) 30 x 18,5 cm / 12.0 x 7.3 inch	1	001.103733
Roaster rectangular (LUKULLUS) 35 x 21,5 cm / 13.7 x 8.5 inch	1	001.103969
Roaster rectangular (LUKULLUS) 38 x 24 cm / 15.0 x 9.4 inch	1	001.104127
Souffle oval (LUKULLUS) 24 x 15 cm / 9.6 x 6.0 inch	1	001.104601
Flan dish round (LUKULLUS) 18 cm / 7.2 inch	1	001.464117
Toothpickholder 5140 5 x 4,5 cm / 1.7 inch	2	001.589846
Creamer 5140	6	001.588541
Sugarstickholder 5140	6	001.588491

¹ PU = Packing Unit

² Item-No refers to undecorated articles

GASTRONORMUNIT

ITEM DESCRIPTION

PU¹ Item-No²

GN-Unit 1/1 1402/121	1	001.591786
GN-Unit 1/2 1402/122	1	001.591836
GN-Unit 1/3 1402/123	1	001.591911
GN-Unit 1/4 1402/124	1	001.591961
GN-Unit 2/4 1402/224	1	001.592011
GN-Unit 1/1 1402/101	1	001.591636
GN-Unit 1/2 1402/102	1	001.591661
GN-Unit 2/3 1402/203	1	001.591686
GN-Unit 1/3 1402/103	1	001.591711
GN-Unit 1/4 1402/104	1	001.591736
GN-Unit 2/4 1402/204	1	001.591761
GN-Unit 1/6 1402/106	1	001.592311





MUG TO GO

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Mug To Go 0,42 ltr. / 14.0 oz.	6	001.751057
	Lid to go	6	001.751058
	Sleeve to go	6	001.751059
	Mug To Go 0,42 ltr. / 14.0 oz.	1	001.751056

¹ PU = Packing Unit

² Item-No refers to undecorated articles

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Mug To Go with handle 0,45 ltr. / 15.0 oz.	6	001.755554
	Lid to go	6	001.751058
	Mug To Go with handle 0,45 ltr. / 15.0 oz.	1	001.755555






C COMMUNITY


	ITEM DESCRIPTION	PU ¹	Item-No ²
	Plate flat with rim 20 cm / 8.0 inch	6	001.743398
	Plate flat with rim 23 cm / 9.0 inch	6	001.743399
	Plate flat 25,5 cm / 10.0 inch	6	001.743400
	Soup plate with rim 25,5 cm / 10.0 inch	6	001.743410
	Plate deep 23 cm / 9.0 inch	6	001.743403
	Salad plate 12 cm / 4.8 inch	4	001.743405
	Salad plate 13,5 cm / 5.4 inch	4	001.743406
	Cup 0,18 ltr. / 6.0 oz.	6	001.743430
	Cup non stackable 0,22 ltr. / 7.3 oz.	6	001.743431
	Saucer 1 15,5 cm / 6.0 inch	6	001.743432
	Mug with handle 0,28 ltr. / 9.3 oz.	6	001.743433
	Mug with two handles 0,28 ltr. / 9.3 oz.	6	001.743434
	Soup cup 0,30 ltr. / 11.7 oz.	6	001.743404
	Saucer 1 15,5 cm / 6.0 inch	6	001.743432
	Coffee pot 1 0,38 ltr. / 12.7 oz.	2	001.743417
	Tea pot 1 0,55 ltr. / 18.3 oz.	2	001.743420
	Warming plate 1069 small	1	001.743435
	Sugar bowl 2 0,28 ltr. / 9.3 oz.	1	001.743423
	Creamer 1 0,15 ltr. / 5.0 oz.	1	001.743426
	Creamer 2 0,25 ltr. / 8.3 oz.	1	001.743427
	Cup 0,09 ltr. / 3.0 oz.	6	001.743429
	Saucer 13,5 cm / 5.4 inch	6	001.743428

¹ PU = Packing Unit

² Item-No refers to undecorated articles

	ITEM DESCRIPTION	PU ¹	Item-No ²
	Plate flat 30 cm / 12.0 inch	6	001.743402
	Plate flat 28 cm / 11.3 inch	6	001.743401
	Plate flat 17 cm / 6.7 inch	6	001.743397
	Salad plate 19 cm / 7.5 inch	6	001.743411
	Pasta plate deep 27 cm / 10.7 inch	2	001.743412
	Gravy boat 0,45 ltr. / 15.7 oz.	2	001.743413
	Bowl round 18 cm / 7.0 inch	2	001.743407
	Bowl round 21 cm / 8.3 inch	2	001.743408
	Bowl round 24 cm / 9.5 inch	2	001.743409
	Oval platter 31 cm / 12.3 x 9.4 inch	2	001.743415
	Oval platter 35 cm / 13.9 x 11.0 inch	2	001.743416
	Vase	1	001.743436
	Candleholder	1	001.743437
	Egg cup with rest	6	001.743414





The saucers are moulded deep so that cups and mugs remain standing safely in the hollow of the saucer, even if tipped to an extreme angle.



The mug handles are designed to be big and easy to grasp. Additional protection prevents users from burning their fingers.





ITEM DESCRIPTION	PU ¹	Item-No ²
Coffee pot 1 0,35 ltr. / 11.8 oz.	2	001.560532
Tea pot 1 0,35 ltr. / 11.8 oz.	2	001.562645
Sugar bowl 2 0,20 ltr. / 6.7 oz.	1	001.564493
Creamer 4 0,15 ltr. / 5.0 oz.	1	001.565946
Creamer 5 0,30 ltr. / 10.0 oz.	1	001.566735
Cup 1 0,18 ltr. / 6.0 oz.	6	001.570565
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Cup 2 0,16 ltr. / 5.3 oz.	6	001.572016
Saucer 13,6 cm / 5.3 inch	12	001.571488
Cup 0,09 ltr. / 3.0 oz.	12	001.569242
Saucer 12,1 cm / 4.7 inch	12	001.568847
Cup 0,22 ltr. / 7.3 oz.	6	001.573468
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Cup 0,23 ltr. / 7.3 oz.	6	001.579671
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.576900
Mug 0,22 ltr. / 7.3 oz.	12	001.577692
Egg cup with rest	6	001.555912
Plate flat with rim 30 cm / 12.0 inch	6	001.547201
Plate flat with rim 27 cm / 10.7 inch	6	001.546541
Plate flat with rim 25 cm / 10.0 inch	6	001.545881
Plate flat with rim 21 cm / 8.3 inch	6	001.545221
Plate flat with rim 19 cm / 7.5 inch	6	001.544692
Plate flat with rim 17 cm / 6.8 inch	6	001.544164
Plate flat with rim 15 cm / 6.0 inch	6	001.543767
Soup plate deep 23 cm / 9.0 inch	6	001.547860
Salad plate deep 19 cm / 7.5 inch	6	001.553404
Soup cup 0,30 ltr. / 10.0 oz.	6	001.549443
Saucer 1 15,1 cm / 5.9 inch	6	001.569905
Gravy boat 0,50 ltr. / 16.7 oz.	2	001.554724
Bowl round 13 cm / 5.3 inch	4	001.549972
Bowl round 15 cm / 6.0 inch	4	001.550500
Bowl round 18 cm / 7.0 inch	2	001.551029
Bowl round 21 cm / 8.3 inch	2	001.551689
Bowl round 23 cm / 9.0 inch	2	001.552348
Oval platter 28 cm / 11.0 x 8.0 inch	2	001.558553
Oval platter 31 cm / 12.2 x 9.1 inch	2	001.559213
Oval platter 35 cm / 13.8 x 10.2 inch	2	001.559872



ITEM DESCRIPTION	PU ¹	Item-No ²
Plate flat with rim 28 cm / 11.0 inch	6	001.492009
Plate flat with rim 25,5 cm / 10.0 inch	6	001.491687
Plate flat with rim 23 cm / 9.1 inch	6	001.491355
Plate flat with rim 20 cm / 7.9 inch	6	001.491111
Soup plate with rim 25,5 cm / 10.0 inch	6	001.494089
Plate deep 23 cm / 9.1 inch	6	001.492341
Cup 1 0,18 ltr. / 6.0 oz.	6	001.494929
Saucer 1 15,5 cm / 6.1 inch	6	001.494587
Mug with handle 0,30 ltr. / 10.0 oz.	6	001.495105
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.495349
Mug with two handles 0,30 ltr. / 10.0 oz.	6	001.495525
Bowl round 16 cm / 6.3 inch	4	001.493239
Bowl round 16 cm / 6.3 inch	4	001.493561
Bowl round 12 cm / 4.7 inch	4	001.493825
Soup cup 0,35 ltr. / 11.6 oz.	6	001.492995
Saucer 17,5 cm / 6.9 inch	6	001.492663
Soup bowl with handle 0,50 ltr. / 16.7 oz. V203	6	001.495975
Compartment system platter 25,5 cm / 10.1 inch V219	2	001.496063



¹ PU = Packing Unit

² Item-No refers to undecorated articles

The famous »icing« on the cake...



Your cooking makes gourmets go into raptures.

The interior, decoration, accessoires, glasses ... **everything is of finest quality.**

There is only a small but essential detail missing

PORCELAIN WITH VIGNETTES



Your personal and distinctive logo on fine porcelain.

We can provide a quote – free of charge and obligation –
and a computer simulation for your customised porcelain.

Send us your templates and we'll do the rest!


SELTMANN WEIDEN –

... FROM SOLE PROPRIETORSHIP TO CORPORATE GROUP

The **Christian Seltmann Porcelain Factory** (SELTMANN WEIDEN), founded in 1910, has evolved, through the takeover of the 'Royal Privileged Tettau Porcelain Factory' (KÖNIGLICH TETTAU) and the four specialist porcelain-manufacturers and art department absorbed in 1990 and 1995 to become a **group of companies** that is still today managed as a **family-run firm**. The group operates four factories employing around 700 people, producing exquisite porcelain for households, marketing – promotion – incentives, hotels and communal catering. It also creates stunning figurines and gifts.

As one of very few porcelain manufacturers to **operate worldwide**, the Seltmann Group possesses an unusually wide range of production expertise: from **high-tech production** in one of Europe's most modern porcelain manufacturing plants to the **craftsmanship** of traditional artisans working by hand at the Rudolstadt workshops in Thuringia.

Consequently, the porcelain produced by the Seltmann Group satisfies even the most exacting international demands in terms of design, function, resilience and exclusivity. It is precisely these product characteristics that can only be achieved at such **high standards** thanks to production in Germany. Reliability and flexibility are very important for the entrepre-



neurial Seltmann family, as well as the development of particularly **environmentally sound production techniques**, which are immediately incorporated into the production facilities.



be green

At SELTMANN WEIDEN, production in accordance with strict **environmental criteria** and **health guidelines** has always been a top priority.

To create a **credible, long-term** means of communicating this **eco-friendly approach** embraced by the whole Seltmann Group, Seltmann has developed an **environmental seal of quality** for its porcelain manufacturing activities.

MADE IN GERMANY

We produce in Germany

With its companies, the Seltmann Group has more than **250 years of experience** in the manufacture of porcelain. The ever-expanding **production expertise** passed down through the generations cannot to this day be replaced.



/seltmannweiden



/seltmannporzellan



/company/porzellanfabriken-
christian-seltmann-gmbh



hotel.seltmann.com

Porzellanfabriken Christian Seltmann GmbH
P.O. Box 2040 | 92610 Weiden/Germany
Phone +49 961 / 204-0
Fax +49 961 / 204-119
E-mail: hotel@seltmann.com

MADE IN GERMANY

We produce in Germany

Your dealer:



AKB Grootverbruik b.v.
Dijnselburgerlaan 3
3705 LP Zeist
030 6950814
www.akb.nl